

Product Name: LED Sensory Carpet

Product Code: SCAR

Specification

Size: 95cm x 95cm

Weight: 2.3KGS

Material: Fabric

Fibre Optic: 160pcs of Fibre optic strands

Contents:

1 x Carpet

1 x USB cable

1 x Non replaceable rechargeable 3.7 Polymer Lithium Li-ion Battery

WARNING!

- Contains sequences of flashing lights which may affect individuals who are susceptible to photosensitive epilepsy or other photosensitivities.
- Please ensure children are always supervised whilst playing on the carpet.

Safety Warnings:

- Please read these instructions carefully before using and retain this information for future reference.
- Before using, ensure the product is not damaged. If any part of the product is damaged, do not attempt to use.
- If the fibre optic stop working, do not attempt to replace.
- Remove all packaging before setup. Do not operate in packaging. Keep packaging away from children and pets.
- Keep away from heat sources or naked flame.
- For indoor use only.

Battery Information

- The carpet is supplied with non-replaceable Lithium Ion battery, do not attempt to replace the battery.
- The battery should be recharged by connecting the supplied micro-USB cables to an available USB port or USB charger. The battery packs is located inside a pouch closed with Velcro, on the edge of the carpet.
- The carpet will flash to indicate charging is taking place, and the lights will go out when charging is complete.
- The carpet will take approximately 4 hours to fully charge when flat.
- Do not leave the carpet on charge for long periods, it is good practice to only charge when it is fully discharged to preserve the useful life of the battery.

Instructions for use

- Press the button located on charging cable to activate the carpet. It will change through a sequence of colour modes with multiple button presses and stay lit for 60 seconds.
- If button is pressed second time, light will turn off.



- Tread firmly on the carpet – it will stay lit for 60 seconds.
- If the carpet no longer illuminates, connect the charger as described in the battery information section.
- To clean wipe with a soft damp cloth.
- Do not immerse in water or wash in the washing machine.
- The carpet can be vacuumed on.



Disposal: The "Crossed Wheelie Bin" symbol on the product means that the product is classed as Electrical or Electronic equipment and should not be disposed with other household or commercial waste at the end of its useful life. The goods must be disposed of according to your local council guidelines.