

**VIBEROZ GIGI**  
**TESTIKEL STIMULATOR**  
**MET COCKRING**



**HANDLEIDING**

# Hoe te gebruiken

- Houd de aan/uit knop een aantal seconden ingedrukt om de vibratie stand aan te zetten. Dezelfde knop gebruik je om te wisselen tussen de 9 vibratie standen.
- De cockring is rekbaar zo kun je deze eenvoudig om de penis krijgen.
- De sleeve bevestig je om de balzak
- Om de vibraties uit te schakelen houd u de aan/uit knop weer ingedrukt.
- De afstandsbediening is automatisch verbonden. Hiermee kunt u, netzoals op het apparaat zelf, van stand wisselen of het apparaat aan/uit schakelen.

# Opladen

- Zodra de trilfunctie van de Gigi zwakker aan begint te voelen of wanneer hij niet aangaat, laadt de vibrator dan op.
- De magneetjes aan het uiteinde van de USB kabel bevestigd u makkelijk op aan de onderkant van de sleeve.
- Bevestig de usb stekker vervolgens in een usb-adapter of een andere usb poort.
- Binnen anderhalf uur is hij vol en weer klaar voor gebruik.
- Gebruik een van de twee meegeleverde knoopcel batterijen voor de afstandsbediening

# Schoonmaken, bewaren en veiligheid

Was de Gigi af onder warm water en met een antibacteriële zeep.

Afspoelen met koud/lauw water en goed afdrogen. Nooit reinigen met middelen die alcohol, benzine of aceton bevatten. Stel de vibrator nooit bloot aan extreme hitte.

# Let op

- Dit is geen medisch hulpmiddel.
- Wanneer ongemak optreed stop dan met gebruiken en raadpleeg professionele medische hulp.
- Niet langer dan 20 minuten de cockring omhouden, bij gevoelloosheid of zwellingen direct af doen.
- Niet gebruiken als het apparaat wordt opgeladen.

# How to use

- Press and hold the on/off button for a few seconds to turn on the vibrator mode. The same button is used to switch between the 9 vibration modes.
- The rings are stretchable, so you can easily get them around the scrotum or penis.
- To turn off the Gigi, press and hold the on/off button again.
- The remote control is connected automatically. Just like on the device itself, the remote allows you to switch modes or switch the device on/off.

# How to charge

- As soon as the vibration function of the Gigi starts to feel weaker or when it does not turn on, the vibrator needs to charge.
- The magnets at the end of the USB cable are easily attached to the back of the vibrator.
- Then attach the USB plug to a USB adapter or another USB port.
- Within an hour and a half it is full and ready for use again.
- Use one of the two included button cell batteries for the remote control

# Cleaning, storage and safety

Wash the Gigi with warm water and an antibacterial soap. Rinse with cold/lukewarm water and dry well with a towel. Never clean with cleaning products which contain alcohol, petrol or oracetone. Never expose the vibrator to extreme heat.

# Pay attention

- This is not a medical device.
- Don't use the cockring for longer than a period of 20 minutes, if your is starting to feel numb or get swollen stop the usage immediatly.
- If any form of discomfort occurs, stop usage and seek professional medical attention.
- Do not use while the device is charging. Attach the DC plug carefully while charging