

# Vibrerende masturbator Handleiding



# Hoe te gebruiken

- Haal de bovenste dop eraf voor gebruik.
- Stop 3 AAA batterijen in de batterijklep onderin.
- Om de trilfunctie aan te zetten draait u aan het wielletje aan de onderkant. Met dit wielletje wisselt u ook van intensiteit.

# Schoonmaken, bewaren en veiligheid

Haal de binnensleeve er uit en was af onder warm water en met een antibacteriële zeep. Afspoelen met koud/lauw water en goed afdrogen. Nooit reinigen met middelen die alcohol, benzine of aceton bevatten. Stel de masturbator nooit bloot aan extreme hitte.



Wielletje voor trilfunctie



Batterij klepje

# How to use

- Remove the top cap before use.
- Insert 3 AAA batteries into the bottom battery cover.
- To turn on the vibration function, turn the wheel at the bottom. You can also change the intensity with this wheel.

# Cleaning, Storage and Safety

Remove the inner sleeve and wash under warm water and an antibacterial soap. Rinse with cold/lukewarm water and dry well. Never clean with resources containing alcohol, petrol or acetone. Never expose the masturbator to extreme heat.



Turning wheel for vibration



Battery cover