

ALPHA HANDLEIDING



HOE TE GEBRUIKEN

- Houd de aan/uit knop een aantal seconden ingedrukt om de vibrator aan te zetten
- Deze zelfde knop gebruikt u om af te wisselen tussen de 9 heerlijke vibratie
- Met de afstandbediening kun je de Alpha ook aanzetten en wisselen tussen vibratie standen.
- Houd de dezelfde knop weer ingedrukt om hem uit te schakelen

OPLADEN

- Zodra de trilfunctie van de vibrator zwakker aan begint te voelen of wanneer hij niet aangaat, laadt de vibrator dan op.
- Steek de DC stekker via het gaatje aan de onderkant (let op: deze is waterdicht afgesloten en kan er voor uw gevoel stroef in gaan)
- Bevestig de usb stekker vervolgens in een usb-adapter of een andere usb poort.
- Binnen anderhalf uur is hij vol en weer klaar voor gebruik.

SCHOONMAKEN, BEWAREN EN VEILIGHEID

Was de vibrator af onder warm water en met een antibacteriële zeep. Afspoelen met koud/lauw water en goed afdrogen. Nooit reinigen met middelen die alcohol, benzine of aceton bevatten. Stel de vibrator nooit bloot aan extreme hitte.

LET OP

- Dit is geen medisch hulpmiddel.
- Nietgebruiken op open wonden of het gebied van je borst en keel.
- Wanneer ongemak optreed stop dan met gebruiken en raadpleeg professionele medische hulp.
- Niet gebruiken als het apparaat wordt opgeladen.
- Bevestig de DC stekker voorzichtig tijdens het opladen

HOW TO USE

- Hold the on/off a few seconds to turn on the vibrator
- Use the same button to switch between vibration modes
- With the remote you can also turn on the Alpha and change vibration modes.
- W Hold the same button to turn of the vibrator

HOW TO CHARGE

- When the vibration function of the vibrator starts to feel weaker or when it does not turn on, the vibrator needs to charge.
- Insert the DC plug through the hole at the bottom (note: this is sealed waterproof and may feel tight)
- Then attach the USB plug to a USB adapter or another USB port.

CLEANING, STORAGE AND SAFETY

Wash the vibrator under warm water and with an antibacterial soap. Rinse with cold/lukewarm water and dry well. Never clean with things containing alcohol, petrol or acetone. Never expose the vibrator to extreme heat.

PAY ATTENTION

- This is not a medical device. Do not use on open wounds or the area of your chest and throat.
- If discomfort occurs, stop use and seek professional medical attention.
- Do not use while the device is charging. Attach the DC plug carefully while charging