


New Experience

Enjoy Multi-function keys and Multiple connection ways



- ① Power Button
- ② Mode Switch Button
- ③ Volume Down/Last Track
- ④ Volume UP/Next Track
- ⑤ Pause/Play/Re-pair Button
- ⑥ Bass/Normal Mode
- ⑦ TF card Slot
- ⑧ AUX-in Port
- ⑨ Mirco-USB Charging Port
- ⑩ Charging Indicator Light
- ⑪ Reset Button

