



CAUTION!


- The tumble dryer is intended only for drying text to material washed in water.
- Disconnect the dryer from the power cord before cleaning or servicing.
- Items containing foam rubber or a heavily textured rubber-like material should not be dried in the dryer.
- Do not allow children to play on or in the dryer.
- Only place sufficiently dehydrated clothes into your dryer for drying.
- The tumble dryer is not to be used if chemicals have been used for cleaning.
- Do not allow lint to collect around the tumble dryer.

WARNING: CLEAN THE LINT TRAP REGULARLY

Cleaning the Exhaust Filters

- Filters must be cleaned after each use.
- Do not use your dryer without the filter.


Assemble sequence



Cleaning the Air Intake Filters

- The filter should be cleaned once a month.

Disassemble sequence



Refer to Use and Care Manual for all instructions.