

Operating instructions: The external flexible cable luminaire shall be destroyed. The lamps are not re on. 2. "TIMER" for switching the light on/off autom press the button on the transformer for 3 seconds (100% - 75% - 50% - 25% - OFF).



Transformator - Transformateur
Transformator - Transformator
IP44



Input: 2
Output:
CBD - P
1738 20