


## Common faults

Common faults	Cause	Exclusion method
Nixie tube display of all functions cannot be started	The water temperature is too high	Please add cold water to cool down
Scale	Heavy or dirty water	Soak with oxalic acid or toilet cleaner for 10 minutes and rinse

## Emergency handling method

1. In case of any abnormality of this product, please turn off the power switch first and then unplug the power plug.
2. If there is a fault that cannot be eliminated by yourself, please do not disassemble and repair it by yourself, so as to avoid danger
3. If the power cord is damaged, do not use it! It must be replaced by the manufacturer or distributor or qualified personnel to avoid danger.



## Foot bath

Product specification

## Use program


### (Style 5) Usage of foot bath

#### 1. Can body extension:

Press and hold the bottom of the barrel, grasp the front and rear barrel edges, lift them up to the maximum position in turn, that is, expand them, and then fix the left and right support frames in the barrel, which can be used.

#### 2.Can body folding collection:

Break off the support frames on both sides of the basin, cross and close to the bottom of the basin, and then press down the barrel edges on the left and right sides to shrink and fold.



Do not put your feet on the basin edge during use

When using, please dial off the battery compartment

## Instructions

Open the package, take out the product, press the bottom of the barrel, lift and unfold it from both sides of the barrel in turn, and fix the left and right inner support frames on both sides of the barrel.

1. Add water into the basin (it is recommended to add warm water below 40 °C), plug in the power supply, and the screen displays off.
2. Press the on / standby key to start the machine. After starting the machine, turn on surfing and heat it to 42 °C for automatic constant temperature.
3. Set the temperature through the heating and desuperheating keys, and adjust it freely at 35-47 degrees. After adjusting the temperature, the screen number will return to the current water temperature. After heating to the set temperature, keep the constant temperature, and the deviation of 1-2 degrees is within the normal range.
4. Adjust the timing time through time setting. It can be adjusted freely for 10-60 minutes. Each time you press the key, the timing time changes for 10 minutes, and the startup timing will be automatically set for 30 minutes.
5. Press the electric massage key once to turn on the function and automatically massage the sole of the foot. Press it again to turn off the function. By default, the program sets the massage time as 15 minutes, and then it will turn off automatically.
6. This machine belongs to touch screen sensing key. Do not splash water or other liquid on the control panel to avoid program error.

- ⊘ It is strictly prohibited to stand for use; Do not use this product on a seat that can slide or shake. Please sit down before soaking your feet to prevent accidental falling injury.
- ⚠ Not suitable for pregnant women and children. If a woman wants to use this product during menstruation, please follow the doctor's advice.
- ⊘ Do not repair the product without authorization. In case of failure, please contact the professional maintenance shop designated by the manufacturer for repair.
- ⊘ Prevent water from entering the control panel area. It is strictly prohibited to immerse the product in water for cleaning or flushing.
- ⚠ If liquid leaks from the appliance, the appliance can no longer be used.
- ⊘ It is strictly prohibited to use after fasting, satiety, drunkenness and vigorous exercise.
- ⚠ Please fill and pour water from the end away from the control panel.
- ⚠ It is forbidden to pull the product with the power cord.
- ⚠ The heater has surface heating, so people who are not sensitive to heat should pay attention to it!

## Technical parameter

Product name	Foot bath
Rated voltage	110V/220V-
Rated frequency	60/50Hz
Rated power	420W/500W
Security category	□
Executive standard	GB4706.1-2005 GB4706.10-2008

**Statement: This product is a daily household maintenance product, not a medical device!**

## Use program


### (Style 3) Usage of foot bath

#### 1. Can body extension:

Press and hold the bottom of the barrel, grasp the front and rear barrel edges, lift them up to the maximum position in turn, that is, expand them, and then fix the left and right support frames in the barrel, which can be used.

#### 2.Can body folding collection:

Break off the support frames on both sides of the basin, cross and close to the bottom of the basin, and then press down the barrel edges on the left and right sides to shrink and fold.



Note: when you feel the temperature is too high during foot bath, please turn off the switch and stop heating!

## Instructions

Open the package, take out the product, press the bottom of the barrel, lift and unfold it from both sides of the barrel in turn, and fix the left and right inner support frames on both sides of the barrel.

Do not put your feet on the edge of the basin during use.

1. After adding water (it is recommended to add warm water below 40 °C), plug in the power supply, according to the function prompt, turn the knob to the surf heating red light bubble gear, and the function is turned on; When you feel the temperature is too high during foot bath, turn the knob to off to stop heating.
2. After use, turn the knob to off, shut down, unplug the power supply and pour out the water.
3. After the machine is started, the temperature will gradually rise to 42 degrees. After the maximum temperature reaches 47 degrees, keep the constant temperature. The deviation of 1-2 degrees is within the normal range.

## Use program

### (Style 1/2) Usage of foot bath

#### 1. Can body extension:

Press and hold the bottom of the barrel, grasp the front and rear barrel edges and lift them up to the maximum position in turn, that is, expand them.

#### 2. Can body folding collection:

Press down on the left and right barrel edges to shrink and fold.



Note: when you feel the temperature is too high during foot bath, please turn off the switch and stop heating!

## Instructions

Open the package, take out the product, press the bottom of the barrel, and lift it up from both sides of the barrel in turn.

Do not put your feet on the edge of the basin during use.

1. After adding water (it is recommended to add warm water below 40 °C), plug in the power supply and press the power switch at the lower right of the foot bath. At this time, the function can be turned on.  
After the machine is started, the temperature will gradually rise to 42 degrees.
2. After the maximum temperature reaches 47 degrees, keep the constant temperature. The deviation of 1-2 degrees is within the normal range.
3. After use, press the power switch at the lower right of the foot bath to turn it off, unplug the power and pour out the water.





## Matters needing attention










In order to ensure safe use and avoid injury and property loss to you and others, you must abide by the following safety precautions.

Failure to observe safety warnings and misuse may lead to accidents.

This product does not consider:

- Use of unattended appliances for young children and the disabled.
- Children's playing equipment.

**Meaning of mark:**  Pay attention  To force  Warn  Prohibit

-  1. To prevent scalding the user's skin due to excessive water temperature, if hot water is added into the machine, please be careful not to add hot water exceeding 40 C.
-  2. Those who are insensitive to heat or have difficulty in moving and children must be accompanied by adults. Those who have foot abscess or skin rupture and other trauma should not use it, otherwise it will cause harm.
-  3. Diabetes, heart disease, mental retardation and mental patients are strictly prohibited.
-  4. If you need to use any medicine other than foot bath medicine, please follow the doctor's advice.
-  5. Do not touch metal conductors, such as metal chairs, radiators and other conductive objects connected to the ground.
-  6. Patients with pacemakers and women who want to use this product during menstruation and pregnancy should follow the doctor's advice.
-  7. It is strictly prohibited to plug the filter screen cover and filter screen, so as not to damage the machine or cause burns.
-  8. If the power cord is damaged, it must be replaced by professionals from the manufacturer, its maintenance department or similar departments to avoid danger.
-  9. It is strictly prohibited to use without water, which may cause damage to machine parts.

## Use program

### (Style 4) Usage of foot bath

#### 1. Can body extension:

Press and hold the bottom of the barrel, grasp the front and rear barrel edges, lift them up to the maximum position in turn, that is, expand them, and then fix the left and right support frames in the barrel, which can be used.

#### 2. Can body folding collection:

Break off the support frames on both sides of the basin, cross and close to the bottom of the basin, and then press down the barrel edges on the left and right sides to shrink and fold.



Do not put your feet on the basin edge during use

## Instructions

Open the package, take out the product, press the bottom of the barrel, lift and unfold it from both sides of the barrel in turn, and fix the left and right inner support frames on both sides of the barrel.

1. Add water into the basin (it is recommended to add warm water below 40 C), plug in the power supply, and the screen displays off.
2. Press the on / standby key to start the machine. After starting the machine, turn on surfing and heat it to 42 C for automatic constant temperature.
3. Set the temperature through the heating and desuperheating keys, and adjust it freely at 35-47 degrees. After adjusting the temperature, the screen number will return to the current water temperature. After heating to the set temperature, keep the constant temperature, and the deviation of 1-2 degrees is within the normal range.
4. Adjust the timing time through time setting. It can be adjusted freely for 10-60 minutes. Each time you press the key, the timing time changes for 10 minutes, and the startup timing will be automatically set for 30 minutes.
5. Turn on and off the surf heating function through the surf heating button.