

NUBEX

Functional Operation Instructions

ios/Android

Turn on bluetooth

Open the earphone box and approach the unlocked mobile phone

Search for Bluetooth device JH-S1-D and click Connect

1

Left Ear Touch



Previous song
(Touch three times)

Voice assistant
(Touch twice)

Answer the phone
(Touch twice)

Refuse to answer the phone
(Press and hold for 2 seconds)

reset (Touch five times)

2

Right Ear Touch



Pause / play
(Touch twice)

The next song
(Touch three times)

Answer the phone
(Touch twice)

Refuse to answer the phone
(Press and hold for 2 seconds)

reset (Touch five times)

3

Charging Indicator Status



When charging
(White light flashes)



When fully charged
(White light is always bright)

4

5

Function Definition Description

Boot: After opening the charging chamber cover, take out the left and right headphones it will boot and automatically match

Shutdown: Headphones are put into the charging warehouse, and the headset is automatically shut down.

Take out the headphones, connect the Bluetooth success, single ear back the warehouse, can use the single ear function

Automatic connection: when the phone has not deleted the paired name of the headset connected, take out the headset can be automatically connected

Basic functions of the charging compartment

TWS automatic pairing: headphones are placed in the charging bin, reopen the charging bin on the cover to take out the headset, the ear chance is left and right automatic pairing

Charging instruction: Give the charging row charging white light, full of electricity, white lights are bright, the headphones are put into the warehouse, the white light flashes

6

The Main Parameters

Bluetooth	v5.3	Headphone Button Control	Touch Control
Frequency Response	20Hz-20KHz	Product Size (Charging Case)	48*55*25mm
Sensitivity	103±3dB	Product Weight	About 33g
Supporting Agreement	SBS,AAC	Packing List	Wireless Headset Set; Charging Cable; Manual
Charging Case	USBType-C		

7

Precautions For Use

The earphone should be stored in a dry and ventilated environment to avoid contact with oil, water and steam, so as not to affect the product performance.

Avoid using irritating, organic solvents or articles containing these ingredients

The earphone should be used correctly and properly according to the requirements. Attention should be paid to the influence of the use environment on the headset. In order to ensure smooth connection, it is recommended that the distance between the mobile phone and the headset should be within 10 meters.

If the headset has other problems such as poor connection or poor communication, please do not remove the headset body and its accessories without permission, otherwise it will not be guaranteed.

To charge the headset, please use the standard car charger or the charger specified by our company.

To ensure your normal use of the headset, please make sure the headset is fully charged.

8

Warranty Card

If there are any functional problems, you can enjoy the warranty service, contact customer service.

Artificial damage, fall, scratch, water, no warranty card is not covered by the warranty.

Customers must fill in all necessary information (name, address, telephone number, purchase date, etc).

During the warranty period, the company is responsible for the maintenance costs, but the freight and other costs are not borne by the company.

Warranty service needs to have a warranty card and operate according to the requirements can guarantee, otherwise no warranty.

Product Number: _____

Customer's Name: _____

Contact Number: _____

Customer Address: _____

Purchase Date: _____

Notices

- If your headset is seriously hot or burnt out during charging, you can see if you are using a charging head with a power greater than 5V2A (if it is greater, you need to replace the charging head with a power less than 5V2A)
- If your earphones cannot be paired with one ear or both ears during use, please refer to the following steps
 - Turn on **bluetooth** and **click ignore/unpair** the connected **bluetooth** name
 - Put the earphones into the charging compartment and then take out the earphones again
 - Click** the **left/right** earphones five times in a row to restore the earphones to factory settings, put them in the compartment and then take out the earphones
 - After the **left/right** earphones are automatically paired, turn on the **Bluetooth** of the mobile phone and reconnect
- If you hear that the headset is intermittent, it may be that there is a lot of signal interference in some places, and the **Bluetooth** headset will interfere with the **Bluetooth** background noise.
 - When the distance between the earphone and the mobile phone is more than 10 meters or there is an obstacle in the middle, it will affect the signal transmission.
 - When there are high-power transmitting devices around, it will affect the signal transmission
 - Tight spaces will also affect signal transmission (such as electronic city, etc.)
- Headphones and speakers will have a slight current sound, mainly due to the surrounding magnetic field and hardware design. The standard is that normal playback of songs is not affected
 - The headset adopts an advanced power-saving design. When the headset is stopped, the machine will enter the standby state. When the earphone receives the user's command information, it will activate the earphone, and sometimes it will make a "pop" static sound (this sound will not be produced during playback)
- If your earphone is monophonic, cannot be paired to the ear, cannot be charged, etc., please fully charge the earphone first, and then check whether there is any foreign object blocking the metal contact point at the bottom of the earphone and the bottom of the earphone cup of the charging compartment, resulting in poor contact, please clean it up Wipe and then connect to use