

### Cleaning Instructions

- Wipe acrylic with a clean soft cloth. Do not use abrasive cleaners as will damage surface.

### Safety Instructions

- This product is for indoor use only.
- Before inserting the acrylic design into the base, please remove the transparent protective film from both sides.
- Do not touch acrylic plate surface with your fingers as this will leave marks and may affect the 3D illusion.



- To insert batteries, slide off battery cover, insert new batteries and replace cover.
- Rechargeable batteries are to be removed from the product before being recharged and should be recharged under adult supervision.
- Do not mix standard and rechargeable batteries or new and old batteries.
- Always insert batteries with the correct polarity.
- Exhausted batteries are to be removed from the product immediately.
- Always switch the lamp off overnight or if left unattended.

### How to Use remote controller

Press the reset button, the lamp will revert to the setting when it was first turned on.

Press arrow button, the lamp will change colour, red, green, blue, yellow, cyan, purple and white.

Press the reset button, the lamp will revert to the setting when it was first turned on. Press dimmer arrow button, the lamp colour will become more brighter or darker.

Press flash button, the lamp will become flashing. (should be in single colour flashing)


Press speed button, the flashing or 7 colour changing can become slower or faster.

Press button 1, the lamp will become regular 7 colour changing automatically (changing slow)

Press button 2, the lamp will become regular 7 colour changing automatically (changing fast)

Press button 3, the lamp will become irregular 7 colour changing automatically (changing fast)

Press button 4, the lamp will become 7 colour interim changing automatically (changing slow)



### 3D Lamp User Guide

Please read all instructions and warnings before use. These instructions are for your safety and to ensure you obtain the best performance from this product. Save these instructions for future reference.

#### Product Specifications:

- Input Voltage: 4.5V-5V
- Power Input: USB Cable (included) or 3x AA Batteries (not included)
- Output Power: 2-2.5W

#### How to Use

- Remove the transparent protective film from both sides of the acrylic plate.
- Place acrylic plate in base.
- Plug in USB Cable to power supply/computer or insert batteries.
- Press the power button to turn on.
- Press the power button to change colour. Each time the power button is pressed, the lamp will change colour. There are 7 colours (red, green, blue, yellow, cyan, purple and white) plus an alternating option.
- Hold switch down for 2 seconds to turn lamp off.