



INFINITY
G O O D S

ELECTRIC OVERBLANKET MANUAL

Infinity Goods B.V.
Spinnerij 55, Amstelveen,
1185ZS, Netherlands,
TEL:+31657039480
info@infinitygoods.eu

This leaflet contains important information.
Keep it for future reference.

Important: Read the following instructions carefully before use.

This over blanket must only be used as described in this manual. After removing your over blanket from its packaging, check for any signs of damage. Keep packaging out of the reach of children. Indoor use only.

INTRODUCTION

Failure to comply with the detailed information below may result in injury or property damage (electric shock, burns, fire, etc). The following safety instructions are intended to protect your health and that of others, but also to protect this heating blanket from damage.

It is therefore imperative to respect these instructions and to transmit them to any other user.

SAFETY INSTRUCTIONS

1. This heating blanket should not be used by people who are insensitive or very vulnerable to heat, as well as very young children (0 to 3 years old), due to their inability to react to overheating.
2. This heating blanket should not be used by young children (3-8 years old) unless the switch has been adjusted by a parent or guardian and the child has received sufficient information to use the blanket heating safely.
3. This blanket can be used by children over 8 years of age, as well as by persons with physical, sensory or mental disabilities and those with little knowledge or experience provided they are monitored or know how to use it safely and understand the risks.
4. Children should not play with the blanket.
5. Cleaning and maintenance should not be performed by unattended children.
6. This heating blanket is not intended for use in hospitals or commercial care homes.
7. Do not push in any needles, pins or sharp objects into this blanket.
8. Do not use the heated blanket folded, wrinkled or with sharp creases.
9. Do not use the blanket if wet or damp. Do not use with wet hands or damp feet.
10. You must only use this heating blanket in conjunction with the switch mentioned on the label.
11. While this heating blanket is working, you should not:
 - place objects on it (e.g. suitcase or laundry basket) ,
 - put any other heat source on it, such as hot water bottles, heating pads, etc.
12. The electronic components of the switch become hot when using the heating blanket.



YOU MUST NOT COVER THE CONTROL SWITCH OR PLACE IT ON THE HEATING BLANKET WHEN IT IS USED. DO NOT PLACE THE CONTROL SWITCH UNDER A PILLOW OR BETWEEN SHEETS.

13. Do not pull, twist or bend the wires too hard. Do not pull or lift the appliance by the supply cord.
14. This heating blanket shall be regularly checked for signs of wear or damage. If this is the case, or if the heating blanket has been used inappropriately or is no longer heating, it must be checked by the manufacturer, a qualified agent or service centre before being used again.
15. If the power supply cable of the electric blanket is damaged, it must be replaced by the manufacturer, or a qualified person to avoid any danger.

16. If you wish to store or fold the product, Make sure it has cooled completely. Do not crush it by placing objects on top. Place in its original packaging if possible.
17. Do not use on a folding bed or check that the blanket or its cord is not pinched or bent.
18. This heating blanket must not be tucked under the bed or used as a mattress.
19. Not suitable for warming animals.

EXPLANATION OF SYMBOLS

	Do not insert pins		Do not dry clean.
	Do not bleach.		Gently wash with Max 30 °C water.
	Do not dry in a tumble dryer.		Cannot be used for children under 3 years old.
	Do not iron.		Do not use folded or creased.


HAND CONTROLLER

- 1) Press Turn on button and hold for 3s to display "0", and press again to open, and press again to off
- 2) Temperature level: +/- from 1 to 10
- 3) Shutdown timer: +/- 1 to 12 hours
- 4) Screen display: setting and timer



OPERATION

- Place the plugin to the input connector at the bottom of the heated blanket as shown below and connect other end to a power source(AC220-240V).



- Make sure that the power socket is nearby and that the power cable does not create a trip hazard.
- To set your heated blanket to the desired temperature level, use the left +/- keys. The temperature will rise gradually until reaching the required temperature.
- Set the desired time of use. The cover will stop automatically thanks to its AUTO STOP function. Note: If you want to prolong the usage time, it is advisable to first cool the heating blanket for a period of 5 minutes before using it again.
- The switch must only be operated after connecting the cover.
- If washed, the unit must only be connected after the cover has completely dried. If using on as of a chair do not wrap it tightly around or sit on it as this may cause the overheat protection system to activate.

ATTENTION ! Your appliance must **ONLY** be used as a heated throw, i.e. over the occupant in the bed, chair or sofa.

CLEANING AND MAINTENANCE

When the electric blanket is not in use & before cleaning, be sure to follow the following instructions:

- Make sure the control is in the " Off " position.
- Disconnect the power plug from the mains socket.
- Disconnect the connector connecting the controller to the BLANKET.
- Allow the heating blanket to cool before cleaning.

ATTENTION ! Do not dry clean the heated blanket. Do not twist to dry. Do not dry in a tumble dryer. Do not use a press or try to iron it.

If the heating blanket is very dirty, we draw your attention to the fact that frequent washing will significantly reduce the life of this product. It is therefore advisable not to hit too often during its lifetime.

If the product is machine washed, use a laundry bag.

It can be washed very gently up to 30°C, with neutral products. Use a detergent for delicate textiles and do according to the manufacturer's instructions. Never connect the cover to dry and dry it out faster For drying, do not hang it with clothes pegs or the like Position it flat preferably. Do not expose the heated blanket to sources of heat such as the sun, radiators, etc.

Reconnect the power cord to the heating blanket only when the connector and fabric are completely dry.

If you do not use the heating blanket for a long time, it is advisable to store it in its original packaging in a dry place and not to place any objects on it.

SAFETY SECURITY

Failure to comply with the detailed information below may result in injury or property damage (electric shock, burns, fire, etc). The following safety instructions are intended to protect your health and that of others, but also to protect this heating blanket from damage.

It is therefore imperative to respect these instructions and to transmit them to any other user.

SAFETY INSTRUCTIONS

- This cover has been fully designed and tested to meet the requirements of European safety standards.

- This cover is safe and can be used at night.

- An electronic sensor mechanism built into the cover protects it from overheating and automatically shuts down the power supply in case of failure.

- The security system constantly monitors the temperature of the cover. If the cover reaches a potentially dangerous temperature, the system cuts off the power immediately.

SAFETY INSTRUCTIONS

The fact that this cover is equipped with a security system does not exempt the user from following these instructions.

- If the cover is damaged or shows signs of wear, do not use.
- Before the first power up of this cover, check that the voltage indicated on the cover label is the same as that of the local power supply.
- Examine the cover regularly & check that the cable jacket is not cracking.
- Always check that the power cable connector is firmly attached to the cover.
- Check the cables and the control box regularly for damage and signs of wet.
- In case of damage, immediately switch off and do not use.
- Any power cord, switch or damaged connector must be replaced by a qualified technician.



Information on Disposal for Users of WEEE

The wheeled bin symbol on the product(s) and/or accompanying documents means that used electrical and electronic equipment (WEEE) should not be mixed with general household waste. For proper treatment, recovery and recycling, please take this product(s) to designated collection points where it will be accepted free of charge.

Please contact your local authority for further details of your nearest designated collection point.

Made in the PRC