

# KEYBOARD + MOUSE

CKU200  
CKW200  
KU200

Quick Installation Guide  
Schnellinstallationsanleitung  
Guide d'installation rapide  
Guía de instalación rápida  
Guida all'installazione rapida  
Verkorte installatiegids


## F-Keys




|             |               |              |
|-------------|---------------|--------------|
| FN + F1= 🎵  | FN + F5= ⏮    | FN + F9= 🏠   |
| FN + F2= 🔊- | FN + F6= ⏭    | FN + F10= ✉️ |
| FN + F3= 🔊+ | FN + F7= ▶️/⏸ | FN + F11= 🖨️ |
| FN + F4= 🚫  | FN + F8= ■    | FN + F12= ★  |

## LED Lights


CKU200 + KU200




CKW200




CKW200 Only



1



2



3

Reset • Zurückstellen • Réinitialiser • Reiniciar • Reset • Resetten

