


Remote Shutter Release





1. Remote Shutter Release

Cable port




Release
button


2. Insert Cable




3. Release Button



Autofocus



Shutter Release



Continuous Shoot



Bulb Function

