

reddot design award winner



Cosori 5.5L Air Fryer CP158-AF

11 Preset Conveniences Eleven presets, one cutting-edge machine. With one-touch selections, the Cosori Air Fryer will manage all the calculations. Whether fries or frittata, all your meals, sides, and desserts are ready to be air-fried. Air frying is known to produce food with 85% less fat than a deep fryer, since it requires little-to-no oil—often just a tablespoon will suffice. Its highly effective air circulation evenly cooks food within while keeping textures crisp. You won't need to fire up an entire oven anymore! Save your time—and your oil.

Features

- > 11 presets for an effortless experiences
- > Red Dot Award, 2019
- Ergonomic Design increasing
- > visibility and ease of use One-touch selections
- > Temperature Range: 170-400°F > FREE Cosori Recipe Book (75-205°C)

- > Time Range: 1–60 minutes
- > Unique Shake Reminder
- Xeep Warm function
- Auto Shutoff function
- Safety features, such as overheat protection
- with 100 recipes!

11 Original Presets

A Cosori Air Fryer means so much more than fries. Serve up egg bakes, impressive sides, desserts, roasted veggies, and just about any protein, expertly cooked.



One-Touch LED Panel

You make the selection, and the machine takes care of the calcula- tions. The LED panel helps you make excellent choices—no matter what food you decide to make.





The Benefit of Preheating

The Benefit of Preheating You won't find a preheating option in many other air fryers. Preheating visibly improves food texture and takes 2 to 5 minutes! That certainly beats the time-consuming preheat- ing of traditional ovens.

Shake & Keep Warm Functions

Enjoy an original Cosori design that comes with a bonus 100 origi- nal recipes, fresh from the Cosori kitchen. That covers two meals a week, for almost an entire year!

Dishwasher Safe


Frying foods doesn't have to mean making a mess. Release the inner basket to remove it, then place it in the dishwasher for cleanup. PFOA-free.

Detachable Basket

A removable inner basket means it's easy to separate and clean the part that gets up close and personal with your food. You can also bring it to where you're preparing food for extra convenience.

Nonstick Basket

Foods are as easy to take out as they were to put in. The nonstick surface of the basket results in less residue left behind. In turn, cleanup won't be so rough.













The COSORI Air Fryer cooks food quickly with a reduced amount of oil and fumes that come with traditional deep frying. Make your favorite fried foods with the same crispy, delicious flavor using little to no oil. Find inspiration for every meal with 100 original, COSORI chef-created recipes. Whether your food is fresh or frozen, you can air fry chicken wings, chicken breast, sweet potatoes, steak, fresh fries, and many more at the touch of a button. When you're done, cleanup is just as easy with nonstick and dishwasher-safe baskets.




Image Link:

https://drive.google.com/drive/folders/1DAF-3gIAOYH4M9JXPg9sAZ3NIym7ZWeP?usp=sharing