

MECHANICAL KEYBOARD FIGHTER 2 VMK88B

Package Contents

1. Mechanical keyboard
2. User manual

Mechanical Keyboard Characteristics

- Material: ABS
- XINDA blue pluggable switches
- Chip: SX83099
- 104 keys with double injection
- 26 keys with anti-ghosting
- 6 colors of LED light, 12 kinds of lighting modes
- USB PVC cable
- Plug and play
- Dimension: 445*155*38.5mm
- Compatible with Windows XP, Vista, Win7/8/10, Linux, Max & Mac

Keyboard Functional Introduction

- 26 keys anti-ghosting: Q, W, E, R, T, A, S, D, F, G, Z, X, C, V, B, M, TAB, CapsLock, Shift_L, Ctrl_L, Alt_L, Space, ↑, ↓, ←, →

- Keyboard backlight adjustment button , total 12 LED modes:

| | |
|-------------------|-------------------------------------|
| Backlight mode 1 | Snake-shaped running horse |
| Backlight mode 2 | wave |
| Backlight mode 3 | Vertical, row by row |
| Backlight mode 4 | Horizontal, line by line |
| Backlight mode 5 | Leaning transformation |
| Backlight mode 6 | Cross lighting |
| Backlight mode 7 | Single Light |
| Backlight mode 8 | Left and right scan |
| Backlight mode 9 | Longitudinal brightening and fading |
| Backlight mode 10 | Dot spread |
| Backlight mode 11 | breathing |
| Backlight mode 12 | Lighting fixed |

- Keyboard backlight brightness adjustment:

Fn + ↑: Increase the brightness of the backlight; 4 gears;

Fn + ↓: Decrease the brightness of the backlight; 4 gears;

- Keyboard backlight running/breathing frequency adjustment:

Fn + ←: Decrease backlight running/breathing frequency; 3 gears;

Fn + →: Increase backlight running/breathing frequency; 3 gears;

- Fn + Win_L: locks Win and APP keys and has a light indicating the current state;

- Fn + [F1 - F12]: Implement multimedia functions

| Key combination | Implementation function | Key combination | Implementation function |
|-----------------|-------------------------|-----------------|-------------------------|
| F1 | Media | F7 | Play/Pause |
| F2 | Volume- | F8 | Next Track |
| F3 | Volume+ | F9 | Email |
| F4 | Mute | F10 | Web/Home |
| F5 | Stop | F11 | ---- |
| F6 | Pre-track | F12 | Calculator |

Safety Instructions

1. Keep the keyboard away from sharp objects that could damage it.
2. Do not put heavy objects on the keyboard.
3. Do not stretch, twist or apply force to the keyboard.
4. To clean the keyboard, gently wipe it using a moist cotton cloth.
5. Make sure the keyboard is turned off before cleaning. Do not use liquid cleanser.