




INSTRUCTIONS

VOLCANO ESCAPE



COLORS AND DECORATIONS MAY VARY.

INCLUDES 1 VEHICLE. ADDITIONAL VEHICLES SOLD SEPARATELY. NOT FOR USE WITH SOME HOT WHEELS® VEHICLES.

REQUIRES 4 AA (LR6) ALKALINE BATTERIES (NOT INCLUDED). DISPOSE OF BATTERIES SAFELY.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE AS THEY CONTAIN IMPORTANT INFORMATION.

5-8

? service.mattel.com

HOTWHEELS.COM

ADULT ASSEMBLY REQUIRED.




FTD61-4B70G1
1101892079-4LB

CONTENTS




Refer to **LETTERS** on toy parts and instructions to help with assembly.

LABEL SHEET




APPLY LABELS









BATTERY INSTALLATION


- Unscrew the battery cover with a Phillips head screwdriver (not included).
- Install 4 new AA (LR6) alkaline batteries (not included) in the orientation (+/-) shown.
- Replace battery cover and tighten screws.
- For longer life use alkaline batteries.
- Replace the batteries if boosters can no longer propel vehicles through track set.
- When exposed to an electrostatic source, the product may malfunction. To resume normal operation, remove and reinstall the batteries.










ASSEMBLY









7. BACK VIEW



8. BACK VIEW




BOTTOM VIEW




ASSEMBLY (CONTD.)


21.




22.




23.



24.




25.




TO PLAY

CONTINUOUS PLAY

1. SWITCH ON THE PLAYSET FOR SPINNING LAVA BLASTS. PULL BACK LAUNCHER & LOAD VEHICLE.




2. TIME IT RIGHT FOR A CLEAR PATH. PRESS TO LAUNCH THROUGH THE LOOP!




ESCAPE PLAY

1. BLOCK THE INNER TRACK. LAUNCH & TRAP THE NEXT VEHICLE!




2. TRAP MORE VEHICLES BY THE VOLCANO!




ESCAPE PLAY (CONTD.)

3. LAUNCH AGAIN TO MOVE DIVERTER.




4. LAUNCH ONCE MORE TO UNLOCK HAZARD GATE & SAVE ALL VEHICLES!




MORE WAYS TO PLAY

CONNECTS TO OTHER HOT WHEELS® SETS (SOLD SEPARATELY).

1.



2.



ADDITIONAL CONNECTORS, TRACKS AND SETS NOT INCLUDED.

©2018 Mattel. Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Services 1-800-524-8697 or 1-877-219-8335 (for products that can be controlled by smart devices).
 Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628 500303. Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312.
 Mattel South Africa (PTY) LTD, Office 102 13, 30 Melrose Boulevard, Johannesburg 2196. Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui,
 HK, China. Tel.: (852) 3185-6500. Diimport & Diedarkan Oleh: Mattel Southeast Asia Pte. Ltd., No 19-1, Tower 3 Avenue 7, Bangsar South City, No 8, Jalan Kerinchi, 59200 Kuala Lumpur,
 Malaysia. Tel: 03-33419052.