© Arlo Technologies, Inc. Arlo, Arlo logo, and Every Angle Covered are trademarks of Arlo Technologies, Inc. Other trademarks are for reference purposes.

Si ce produit est vendu au Canada, vous pouvez accéder à ce document en français canadien à *arlo.com/docs*.

(If this product is sold in Canada, you can access this document in Canadian French at *arlo.com/docs*.)

For regulatory compliance information including the EU Declaration of Conformity, visit www.arlo.com/about/regulatory/.



Arlo Technologies Intl. Ltd. Ground Floor, Building 3 University Technology Center Curraheen Road, Cork, T12 EF21 Ireland



## Set up your Arlo Video Doorbell

The Arlo Video Doorbell requires a wired doorbell and chime with voltage between 16 – 24VAC and a 10VA transformer.

If a new transformer is required, we recommend that you have it installed by a certified electrician.

- Download the Arlo app and follow the setup instructions for your Arlo Video Doorbell.
- 2. Install the Power Kit.
- 3. Replace your existing doorbell with your Arlo Video Doorbell



WARNING: To prevent fire and injury, connect the Arlo Video Doorbell and Power Kit only to voltage between 16 – 24VAC.












## What's in the box



Doorbell and plate (These parts are attached.)



Angled mounting plate



Power Kit



Release pin





Wall screws and anchors







Optional wire extensions, wire fasteners, and extra screws

## Tools

- A Phillips screwdriver is required to install the doorbell (not provided).
- You might also benefit from having a drill, a level, and a ladder (to reach the chime).

## Need help?

We are here for you.

Visit www.arlo.com/support for quick answers and resources:

- How-to videos
- Troubleshooting tips
- The Arlo Support phone number for your location