

K1私密剪说明书 单面尺寸70*90mm 摊开尺寸210x90mm 2022.11.2

70mm

70mm

70mm

90mm

Environmental protection

- * The built-in charging battery contains environmentally polluting substances. Always remove the battery when discarding the product and send the battery to the official designated recycling point.
- * Please confirm that the battery is removed when the electrical power is off and the battery life is full. If the machine is still running, use the machine until it stops.

Technical parameter:

Input voltage: 110-240V~
 Power supply: DC5V/1A
 Power: 5W
 Charging time: 90min
 Working time: 60-75min



IPX5 Washable

GROIN TRIMMER INSTRUCTION MANUAL



MODEL NO.:K1

Accessories



1. Stainless Steel Blade
2. Ceramic Blade
3. Blade Direct Shot Lamp
4. Waterproof Sealing Ring
5. ON / OFF Switch
6. LCD Display
7. Cut-Guide Combs (1-3 / 2-4 mm)
8. USB Charging Cable
9. Cleaning Brush
10. Charging Base

Notes before use

- * This specification shall be read in detail before use and kept properly for future review.
- * Access to people with physical, sensory, or mental disorders must have prior training in safe use and be informed of the possible dangers that the product may cause.
- * Children are not allowed to play with the appliance, and shall not maintain or clean the appliance without adult care.
- * Must check the appliance before use. Do not use the appliance if it is damaged, otherwise it will cause damage to the body. Damaged parts must be replaced with the original parts of the same model.
- * The appliance has waterproof sealing ring has waterproof function, can be rinsed under the faucet, but do not soak in water.
- * Please keep the oil bottle out of the reach of children. Do not clean appliances, such as acetone or gasoline, with grinding cleaners or corrosive liquids.

How to use

- * If you are getting ready to use the appliance, check that the LCD display is charged; turn off the appliance before charging. The appliance is equipped with USB charging line for convenient charging, also you can use the charge base to charge. When you use the charging base to charge, you need to connect the line to the base. The charging symbol of the display will flash and display how much power, charging time is about 1.5 hours and working hours is about 1 hours.

- * The appliance can cut the body hair, and the direct light on the knife head can illuminate where you cut to facilitate cutting and check if the cutting is clean.
- * The appliance has 2 limit combs (1-3/2-4/mm), please turn off the power when loading the limit comb, insert the limit comb from the head of the cutting knife, the back of the body buckle, buckle with a slight buckle sound; the limit comb please choose from high to low until your suitable length is found. Point the knife head toward the direction of hair growth when cutting.

Cleaning and maintenance

- * Make sure the appliance is closed when cleaning.
- * The body can wipe with a wet and soft cloth, the knife head can be unloaded, after removing, clean the hair inside the knife of the head of the body with a brush. After cleaning, install the knife head and drop 2-3 drops of oil on the knife head cutting position, so that the machine can operate for a few seconds to lubricate it properly.