


SKIBBI

CPSB01




Užívateľská príručka
 Uputački priručnik
 Fehasználói kézikönyv
 Рководство на употребител
 Manual de utilizare
 Korisnički priručnik
 Εγχειρίδιο Χρήστος

(CZ) (SI) (HU) (BG) (FR) (ES) (IT) (PT) (PL) (JP) (HR) (GR)


User Manual
 Montageanleitung
 Gebruikershandleiding
 Guide d'utilisation
 Instrukcja obsługi
 Manual del Usuario
 Manual do utilizador

(AR) Manual
 (KR) 사용 설명서
 (CN) 使用说明书
 (TH) คู่มือการใช้งาน
 (FI) Käyttöohje
 (NO) Brukerveiledning
 (SE) Bruksanvisning
 (DK) Brugervejledning
 (RU) Руководство по эксплуатации


1




2




3




4



5



✓



The Chillafish Company n.v.
 Straatsburgdok Noordkaai 21 b19
 2030 Antwerpen, Belgium

www.chillafish.com

man_CPSB01_V1.0_MULTILANG

Thanks for choosing Chillafish and trusting your little one to discover the world on one of our toys. The honour is ours.
 Share your fun with us online because we absolutely love to see pictures of all Chillafish-kids! You can find us on Facebook and Instagram.
 Don't forget to register your product to have 5 years extended warranty.

YAY!



5 YEARS
 EXTENDED WARRANTY
www.chillafish.com/register





WARNING

To avoid serious injury

Not suitable for children under the age of 36 months due to small parts which may present a choking hazard.

For use outdoors only.

Do not aim at eyes or face. Do not aim at animals.

Remove completely all plastic tire and packaging before giving this toy to children.