

DRINKFONTEIN

Gebruikshandleiding



INHOUDSOPGAVE

- 1 Inhoud van de verpakking
- 2 Product overzicht
- 3 Product specificaties
- 4 Onderhoud en reiniging
- 5 Gebruiksaanwijzing
- 6 Waterpomp onderhouden

1. INHOUD VAN DE VERPAKKING

Controleer of alle accessoires in de verpakking zitten en de staat van alle onderdelen. Licht ons in bij schade of het ontbreken van onderdelen.

- 1x Gebruiksaanwijzing
- 1x Drink tray
- 1x Filter tray
- 1x Water reservoir
- 1x Buitenbak
- 1x Tuit
- 3x Koolstoffilter
- 1x AC Pomp
- 1x USB-C kabel

2. PRODUCT OVERZICHT

NL



3. PRODUCT SPECIFICATIES

Opslag capaciteit	3L
Afmetingen	19 x 19 x 13,5 cm (l x b x h)
Input voltage	DC 5V
Stroom verbruik	1,5W
Materiaal	ABS / PP
Gewicht	1,2kg
Overige materialen	Geactiveerde koolstof + vezels + hars

4. ONDERHOUD EN REINIGING

Het goed onderhouden van de waterfontein is belangrijk voor het duurzaam gebruik van het apparaat.

- Reinig de filter regelmatig met water.
- Vervang de filter om de 30 dagen.
- Reinig het waterreservoir om de zeven dagen met water.
- Zorg ervoor dat er altijd schoon drinkwater in de fontein aanwezig is.
- Vervang het water in het reservoir om de vijf dagen met vers water.


5. GEBRUIKSAANWIJZING

NL

Belangrijk: Voordat de drinkfontein gebruikt wordt, dienen eerst alle onderdelen uit elkaar gehaald en grondig met water gereinigd te worden.



1 Sluit de AC pomp aan op de desbetreffende plek in het waterreservoir.



2 Trek de kabel van de AC pomp door de buis. Deze zal aan de achterkant van het waterreservoir uit steken.




3 Gebruik de rubberen afsluiter om de kabel te vergrendelen.



4 Vul het waterreservoir met water. Houdt het water onder het aangegeven maximum niveau.



5 Plaats de deksel boven op het waterreservoir. Plaats daarboven de filter en druk deze stevig aan.



6 Verbindt de USB-C kabel met een willekeurige adapter en sluit deze aan op het stopcontact.



7 Plaats de tuit van de waterpomp boven op het deksel. Na het aanzetten van de waterfontein begint deze het water rond te pompen. Dit maakt een licht geluid.



8 De fontein is klaar voor gebruik. Voeg de tuit toe voor een fonteinachtige stroom. Gebruik zonder de tuit creëert een zacht stromend wateroppervlak waaruit jouw huisdier gemakkelijk kan drinken.

6. WATERPOMP ONDERHOUDEN

- 1 Voorkom lekkage van de drinkfontein door middel van het gebruiken van de rubberen afsluiter.
- 2 Zorg er ten alle tijden voor dat er voldoende water in het waterreservoir zit.
- 3 Indien de drinkfontein door meerdere huisdieren tegelijkertijd wordt gebruikt, dient de filter om de 15 dagen vervangen te worden.
- 4 Houdt rekening met het schoonmaken van de waterpomp. Let hierbij extra op het verwijderen stof en vacht van de huisdieren.

CE Met deze markering verklaart de fabrikant dat het product voldoet aan de eisen van de toepasselijke EG-richtlijnen.

PET FOUNTAIN

User manual



TABLE OF CONTENTS

- 1 Contents of the package
- 2 Product features
- 3 Product specifications
- 4 Maintenance and cleaning
- 5 How to use
- 6 Maintaining the waterpump

1. CONTENT OF THE PACKAGE

Check if all accessories are in the package and the condition of all parts. contact us in case of damage or any missing parts.

- 1x User manual
- 1x Fountain tray
- 1x Filter tray
- 1x Water reservoir
- 1x Outer container
- 1x Sprout
- 3x Carbon filter
- 1x AC Pump
- 1x USB-C cable

2. PRODUCT FEATURES

EN



3. PRODUCT SPECIFICATIONS

Capacity	3L
Dimensions	19 x 19 x 13,5 cm (l x w x h)
Input voltage	DC 5V
Power consumption	1,5W
Material	ABS / PP
Weight	1,2kg
Other materials	Activated carbon + fibre + resin

4. MAINTENANCE AND CLEANING

Proper maintenance of the water fountain is important for its long-lasting use.


- Clean the filter regularly with water.
- Replace the filter every 30 days.
- Clean the water tank with water every seven days.
- Make sure there is always clean drinking water in the fountain.
- Replace the water in the water tank with fresh water every five days.

5. HOW TO USE

Important: Before using the water fountain, remove all parts and clean them thoroughly with plain water.



1 Connect the AC pump to the appropriate place in the water tank.



2 Extend the AC pump cable through the tube. It will stick out at the back of the water tank.




3 Use the rubber seal to lock the cable in place.



4 Fill water into the water tank. Keep the water below the indicated maximum water level.



5 Place the lid on top of the water tank. Place the filter above it and press firmly.



6 Connect the USB-C cable to any random adapter and plug it into the wall outlet.



7 Place the fountain tray on top of the lid. After turning the water fountain on, it will start pumping water around. This will make a light sound.



8 The fountain is ready for use. Add the sprout for a fountain-like flow. Use without the sprout creates a gently flowing surface of water from which your pet can drink.

6. MAINTAINING THE WATERPUMP

- 1 Prevent leakage from the drinking fountain by using the rubber seal.
- 2 Make sure that there is sufficient water at all times in the water tank.
- 3 If the drinking fountain is used by several pets concurrently, the filter should be replaced every 15 days.
- 4 Be cautious when cleaning the AC pump. by removing all dust and fur from the pets. This will enable the water to flow freely through the pump.



With this marking, the manufacturer declares that the product meets the requirements of the applicable EC directives.