

Tip

01



If the printer displays a message such as “Non-OEM”, “Not Genuine”, “Non Original” Ink Cartridges after installation, please click “OK” or “Next” to continue. Pls be assured that the printer will work fine.

Tip

02



If the prints come with color fading, streak or broken lines, please try to clean the printer head and nozzle for several times.

Tip

03



If the printer cannot recognize the ink cartridges, please take out them and turn off the printer. After cleaning the contact chips with a soft eraser, then turn on the printer and re-install.

Tip

04



The printing quality may be bad if any dirt, dry ink or paper dust clogging the nozzle. Please Check the Nozzle in the printer SETTING if the prints don't get better after Tips 2 or Tips 3.