

Multifunctional Steam Brush

- Please push down Control switch on the side of handle and then fold the handle.
- When using for the first time, the blue indicator light flashes. Do not turn on the steam button (to avoid water leakage). When the blue indicator turns red, it can be used only after the heating is completed! (blue and red are used alternately in the later use)
- First use it is normal to appear a little smoke, odor and sounds caused by the internal environmental friendly oil evaporating at high temperature and this phenomenon will disappear over time.
- Just start up or water tank water too little, hear the motor rattle idling sound, because there is air in the suction hose, when the air is discharged or the water tank is full of water, the motor clattering sound will disappear!

