330ml, 460ml and 620ml TWIST 'N' SIP™ Bottle



1. Place cap in boiling water for 30 seconds and remove cap safely after time is up. Put cap back on bottle.




2. Whilst still hot, twist cap so that nozzel is open. Using thumbs, apply pressure between cover and base to release cover.



A Caution: Be careful when using boiling water.



3. Wash the components in the dishwasher (top rack only), or wash in hot soapy water.



4. To reassemble, place cover onto base and align indicator tabs.



5. While holding down the nozzle, twist the base onto cover. Then firmly press the cover and base together until it



6. Place cap back on bottle and check cap function. Enjoy!

Please visit the Sistema website for more information and cleaning videos.