

FOR AGES 3 AND UP

Imported by:

United Entertainment B.V.  
De Gaffel 25  
9206 AV Drachten  
The Netherlands

Made in China

PO#50004355



# Bubbles



Distributed by Imported by  
CHANNEL DISTRIBUTION UNITED ENTERTAINMENT  
De Gaffel 25,9206AV Drachten The Netherlands  
02278 02278 Bubble Gun with Light and Sound




8 7 1 8 2 7 4 5 4 8 4 8 8


GB Not suitable for children under 3 years of age. Contains small parts.

### 1. Insert Batteries:



If batteries are inserted wrong, it does not work. Please reverse the battery direction.



### 2. Pump water through the tube by pulling trigger for 15 seconds.



### 3. Screw the bottle of bubble liquid into as shown. The tube must go inside of bottle.



### 4. Pull trigger 5-6 times to make endless bubbles.



MADE IN CHINA

**WARNING:**  
CHOKING HAZARD - Small parts.  
Not for children under 3 years.

صنعت وفقاً للمواصفات والمعايير العالمية  
Tested according to international standards

NOT SUITABLE FOR CHILDREN UNDER 3 YEARS DUE TO SMALL PARTS  
هذه اللعبة غير مناسبة للأطفال تحت سن 3 سنوات بسبب  
القطع الصغيرة.  
COUNTRY OF ORIGIN: CHINA  
بلد المنشأ: الصين

- NO:LS6308  NO:LS6308-1
- NO:LS6308-2  NO:LS6308-3
- NO:LS6308-4  NO:LS6308-5