

A: Take out water tank cover




B: Filling the water in water tank




Product side placement.



Operation and ironing:



Spray button



When you finished iron clothes?
Pls take out the power cord plug
and take out the water from the
water tank.

When the soleplate temperature lower?
so you can put the soleplate in to silica cover.

