


The logo for FINEZA is centered within a white square, which is itself set against a larger, light pink rectangular background. The word "FINEZA" is written in a clean, black, sans-serif typeface.

FINEZA

Föhnborstel Handleiding



Inhoudsopgave/ Table of content


Nederlands

Productoverzicht	1
Het pakket Bevat	2
Functies	2
Hoe de Styling te Veranderen Bijlagen:	3
Waarschuwingen	4

English



Product Overview	5
Package Includes	6
Features	6
How to Change the Styling Attachments	7
Warnings	8

Product Overzicht:



Het Pakket Bevat:

1. 2-in-1 multifunctionele föhn
2. Föhnborstel
3. Krullende opzetborstel
5. Kam opzetstuk
6. Borstel opzetstuk
7. Föhn opzetstuk
8. Gebruikershandleiding




Funcities:

- 360-rotatie
- Thermoprotect
- Drie stappige schakeling

Hoe de stylingborstel te veranderen:

1. Kies je gewenste stylingborstel.
2. Monteer het gekozen hulpstuk op de behuizing van het apparaat door de gleuf op elkaar uit te lijnen




3. Druk het opzetstuk naar beneden om het goed vast te zetten.
4. Om het opzetstuk te verwijderen, trekt u het er voorzichtig af.

Waarschuwing:

- Niet onderdompelen in water.
- Gebruik het apparaat niet in een vochtige badkamer.
- Controleer voordat u het apparaat inschakelt of de spanning van de voeding overeenkomt met 220-240V.
- Bedek de in- en uitgang niet, dit kan leiden tot verbranding of schade aan het mechanische.
- Houdt papier of andere brandbare materialen uit de buurt van de haardroger, dit kan leiden tot een brand.
- Gebruik de haardroger niet naast gas of andere licht ontvlambare voorwerpen.
- Druk geen naald of ander voorwerp in de haardroger. Dit is niet geschikt voor de in- en uitgangen, anders veroorzaakt u schade aan de haardroger en kan leiden tot elektrische schokken.
- Maak alle onderdelen van de haardroger schoon met een zachte en met een natuurlijk schoonmaakmiddel ingesmeerde doek.
- Gebruik nooit middelen als olie of alcohol.
- Bewaar de haardroger niet in de badkamer doucheruimte en andere ruimtes die vochtig zijn.
- Indien beschadigd, moet het worden vervangen door een professionele technicus.
- De föhnborstel heeft een schakelaar van onder naar boven, de eerste versnelling geeft koude wind, de tweede versnelling geeft lage temperatuur, en de derde versnelling geeft een hoge temperatuurcurve; om het apparaat uit te schakelen schuif je de versnelling geheel omlaag.




Product Overview:

Hair Dryer



Package Includes:

1. 2-in-1 multifunctional hair dryer
2. Hair dryer brush
3. Curly brush head
5. Comb attachment
6. Brush attachment
7. Hair dryer attachment
8. User Manual




Features:

- 360-degree rotation
- Thermo protect
- Three head conversion

How to Change the Styling Attachments?

1. Choose your required styling brush.
2. Fit the chosen attachment onto the body of the unit by lining it up with the groove



3. Press the attachment downwards to fix it well.
4. For removing the attachment gently pull it off.

Warnings:

- Do not immerse in water.
- Do not use in a moist bathroom.
- Before turning on the device, check that the voltage of the power supply matches 220-240V.
- Do not cover the input and output, this may cause burning or damage to the device.
- Keep paper or other flammable materials away from the hairdryer, this could lead to a fire.
- Do not use the hair dryer next to gas or other highly flammable objects.
- Do not press a needle or other object into the hairdryer.
- Do not use the hair dryer in the bathroom.
- Clean all parts of the hairdryer with a soft cloth rubbed with a natural detergent.
- Never use substances such as oil or alcohol.
- Do not store the hairdryer in the bathroom, shower room and other areas with moisture.
- If damaged, it should be replaced by a professional.
- The hand dryer brush has a switch from bottom to top, the first gear gives cold wind, the second gear gives low temperature, and the third gear gives a high-temperature curve; to turn off the device, turn down the slide.

F-Group
Made in PRC
Designed in the Netherlands
Bosbeemd 1, Beek en Donk

