



USB desk fan

USER'S MANUAL

Usage instruction

The fan can get supplied from the normal USB chargers for mobile phone, computer USB output, laptop USB output, power bank USB output and other weak current USB outputs.


Product specification

Product Size: 123mmX123mmX50mm
Input: DCSV/1A
Weight: 169g
Standard: GB4706.1-2005


Cleaning method

When the stain is serious, wipe it with a small amount of neutral detergent or soapy water diluted with water and then dry it with a dry cloth.

Do not use volatile oil, thinner or spray cleaner when cleaning the dirt on the shell.



Switch button
Press on
The boot is in first gear
Press again in second gear
Press it three times in third gear
Press last to turn it off



The body rotates to any Angle you want

NOTES

Do not connect the fan to the unexpected power source which over its rated power, which may cause fire, heat or malfunction.

Do not use it in case of failure or damage.

Do not use it in the following situations which may cause fire, electric shock, etc.

*The vicinity of a heating device, such as a heater, or a naked flame.

*Strong direct sunlight, and hot places such as inside the cars under the hot sunlight.

*Close to places where inflammable organic solvents (e.g. diluents, coatings, etc.) and gas is used.

*Far away from children's reach.

Do not remove the grille for other using. It may cause injury, failure or damage. Do not insert fingers or other stuff into the grating, which may cause injury, malfunction and damage.

Do not remove unspecified parts, which may cause injury, failure and damage. Please keep in a safe place to avoid falling down, causing injury, failure and damage. Do not cover the grating cloth to avoid injury, failure and damage. Please follow the following precautions for USB cable, otherwise it may cause injury, device malfunction and damage.

*When ceaning or not using, be sure to remove the USB plug from the USB port.

*Pulling the USB cable with strength may damage the cable segment, please be sure to grab the plug part to pull out or plug in.

*When wirng, be careful to place the wire where you will not trip.

*Do not swing the USB cable to make it fall down under strong impact.

*Do not hang any items on the USB cable. Wrap them too tightly to cause damage.

*Do not modify or twist USB cable.

Do not make this product suffer excessive impact. may cause failure or damage.