




Forward Turn

TV Mount Large

- TV

40-77 inch
- KG


45 kg max
- 600x400 VESA max







Installation
video

M001855_00




3








4



Note: If the display does not stop
at your desired position, adjust the
screws as shown.




 A (x1)  B (x2)	A  C (x4)	B  M-A (x4) M6x14  M-B (x4) M8x16  M-C (x4) M6x30  M-D (x4) M8x35  M-E (x4) D8  M-F (x4) Ø15xØ8x5  M-G (x4) Ø15xØ8x15	C  D (x1) 4mm  W-A (x6) ST6.3x55  E (x1) 10-13mm  W-B (x6) Ø10x45  W-C (x6) D6
---	---	---	--









1
















Ø4.5mm
(Ø3/16'')

← 55mm (2.2'')






W-A, W-B, W-C














Ø10mm
(Ø3/8'')


← 60mm (2.4'')





W-A, W-B, W-C


2





TOP




Too Long Too Short





M-A



M-B



M-E



M-C



M-D



M-E



M-F



M-G