# Dieux®

Elektrische pepermolenset

Electric Salt & Pepper mill set



Gebruiksaanwijzing

Manual

EN Thank you for purchasing the electric grinder set.

## BEFORE USING FOR THE FIRST TIME

To ensure safety and maintain the high quality of the product, we recommend that you read and follow the instructions carefully.
· Do not immerse the appliance in water or any other liquid to avoid harm to human or the product.
· Use for pepper and salt only, please do not use for others purposes.
· Do not force the grinder to tighten or twist it or attempt to speed up the mechanism.
· Keep body parts (e.g. finger) and utensils away from the grinding head to avoid damage. Please hold the grinder tightly when using.
· Keep this product away from children.
· Do not dismantle the product by yourself, or otherwise warranty will be invalid.
· Please take out the batteries if do not use for a long time.
· Keep away from flammable, explosive gas, high temperature.
· Using the product in any manner not described in these instructions releases the manufacturer from all liability.

## PRODUCT DESCRIPTION







1. On/Off Button
2. Upper Body
3. Battery Cover
4. Container
5. Container Cover
6. Light
7. Adjuster
8. Charging & Storage Base
9. Type-C Charging Cable

## HOW TO INSTALL THE BATTERIES

· Press the battery cover with fingers and pull it up by force to open the battery cover.
· Insert 4 pieces of AAA batteries according to the positive and negative terminals.
· Close and lock the battery cover.



## HOW TO CHARGE

· Connect the Type-C charging cable with an adapter, plug the adapter into an electric socket, then connect the charging cable to the Type-C interface at the back of the base.
· It takes 16 hours to fully charge the battery.



*It is recommended to use 4 AAA rechargeable batteries for this product.
*The charging function of this product is only for the use of rechargeable batteries. When using alkaline batteries, do not charge, otherwise it will cause the alkaline batteries to become hot, leaking, and damage the product.
*Adapter is not included with this product. Charge with UL/GS or equivalent safety approved adapters with output voltage of 5V⎓.
*Before connecting to the power source, ensure the adapter, charging cable plug, and the charging port on the device are completely dry.
*Always disconnect the device from the power supply if it is to be left unattended.
*Before each use, check that the appliance and cord are in good condition. Never use the appliance if the cord is damaged.
*Please clean the charging base regularly with a brush to ensure that no abrasive particles contact the charging contact pieces on the base, and avoid poor charging contact.

## HOW TO USE

· Push the container cover with fingers, and put pepper or salt into the container, then restore and lock the cover.

· According to the personal needs to rotate the adjuster.

· Press and hold the on/off button to grind, release the button to stop.

*This product adopts an adjustment knob. The adjuster could be rotated for multiple circles between the finest and the coarsest grinding.
· Adjust to Fine: Rotate the adjuster from “COARSE” to “FINE”. Continue to rotate for a few circles until the desired fineness is achieved.
· Adjust to Coarse: Rotate the adjuster from “FINE” to “COARSE”. If the adjuster loosens, it could be caused by some pepper grains stuck in the burr. Start the product to rotate for 1 second, then the burr will be loosened and you can continue to adjust. This is a normal situation of ceramic burr and will not affect its normal use.
*If the adjuster falls off, please assemble the components in the orders shown below.

*With seasonings in the container, please do not turn the grinder upside down for a long time in case grains of seasonings might get into the battery compartment and cause battery corrosion.

## TROUBLESHOOTING

If the grinder does not work or stops while grinding:
· Please check that the batteries are installed correctly.
· Please confirm there is sufficient battery power.
· If using rechargeable batteries, please charge it before use. (Note: It is not recommended to use the product while charging.)
· Please adjust the adjuster with counter-clockwise direction.
If the above operations are all correct and the grinder still works abnormally, please contact the vendor for maintenance service.

NL Bedankt voor uw aankoop van de elektrische molenset.

## VOOR GEBRUIK VOOR DE EERSTE KEER

Om de veiligheid te garanderen en de hoge kwaliteit van het product te behouden, raden we aan om de instructies zorgvuldig te lezen en op te volgen.
· Dompel het apparaat niet onder in water of andere vloeistoffen om schade aan mens of product te voorkomen.
· Alleen te gebruiken voor peper en zout, niet voor andere doeleinden.
· Forceer de molen niet door deze vast te draaien of de werking te versnellen.
· Houd lichaamsdelen (bijv. vingers) en keukengerei weg van de maalzone om schade te voorkomen. Houd de molen stevig vast tijdens gebruik.
· Houd dit product buiten bereik van kinderen.
· Haal het product niet zelf uit elkaar; dit maakt de garantie ongeldig.
· Verwijder de batterijen als u het product lange tijd niet gebruikt.
· Houd het uit de buurt van brandbare stoffen, explosief gas en hoge temperaturen.
· Gebruik op een andere manier dan beschreven in deze handleiding valt buiten de aansprakelijkheid van de fabrikant.

## PRODUCT BESCHRIJVING







1. Aan/uit-knop
2. Bovenkap
3. Batterijcompartiment
4. Container
5. Deksel van de container
6. Licht
7. Afsteller
8. Oplaad- & opslagstation
9. Type-C oplaadkabel

## HOE BATTERIJEN TE INSTALLEREN

· Druk met uw vingers op het batterijdeksel en trek het omhoog om het te openen.
· Plaats 4 AAA-batterijen volgens de aangegeven plus- en minpolen.
· Sluit en vergrendel het batterijdeksel.



## HOE OP TE LADEN

· Verbind de Type-C oplaadkabel met een adapter, steek de adapter in het stopcontact, en verbind dan de oplaadkabel met de Type-C-poort aan de achterkant van het basisstation.
· Het opladen van de batterij duurt 16 uur.



*Aanbevolen wordt om 4 AAA oplaadbare batterijen te gebruiken.
*Opladen is alleen bedoeld voor oplaadbare batterijen. Gebruik geen alkalinebatterijen voor het opladen om lekkage of schade te voorkomen.
*Adapter wordt niet meegeleverd. Gebruik een goedgekeurde adapter (UL/GS of gelijkwaardig) met een output van 5V⎓.
*Zorg ervoor dat adapter, oplaadkabel en poorten volledig droog zijn voor aansluiting.
*Altijd loskoppelen van het stroomnet als het apparaat niet gebruikt wordt.
*Controleer voor elk gebruik of het snoer en apparaat in goede staat verkeren. Gebruik het apparaat niet als het snoer beschadigd is.
*Reinig regelmatig het laadstation met een borstel om slechte laadcontacten te voorkomen.

## HOE TE GEBRUIKEN

· Druk het deksel op de container en vul met peper of zout. Plaats het deksel terug.

· Draai de afstelknop volgens de gewenste grofheid.




· Houd de aan/uit-knop ingedrukt om te malen, laat los om te stoppen.

*Dit product heeft een afstelknop waarmee u meerdere rondes kunt draaien tussen grof en fijn malen.
· Fijn afstellen: Draai van "COARSE" naar "FINE". Blijf een paar rondes draaien tot gewenste fijnheid is bereikt.
· Grof afstellen: Draai van "FINE" naar "COARSE". Als de knop los zit, kan dit door peperkorrels in de maalschijf komen. Draai het product 1 seconde aan om deze los te maken. Dit is normaal en heeft geen invloed op de werking.
· Als de afsteller loskomt, zet de onderdelen dan terug volgens het onderstaande schema.

Laat de molen niet ondersteboven staan met kruiden in de container. Dit kan leiden tot corrosie van het batterijcompartiment.

## TROUBLESHOOTING

Als de molen niet werkt of stopt tijdens het malen:
· Controleer of de batterijen correct geplaatst zijn.
· Controleer of er voldoende batterijvermogen is.
· Laad oplaadbare batterijen volledig op vóór gebruik. (Het wordt afgeraden het product tijdens opladen te gebruiken.)
· Stel de afstelknop tegen de klok in bij.
Als alle bovenstaande punten kloppen en het probleem blijft bestaan, neem dan contact op met de verkoper voor onderhoudsservice.


Dieux® by FKJ Trading
Hanzeplein 11-27
8017 JD Zwolle
The Netherlands
info@fkjtrading.nl