

picun

BG-01

USER MANUAL

深圳市品存数码科技有限公司

LED Indicator Description

Pairing	Flash in red and blue
Power ON	Steady blue for 3 seconds
Stand By	Steady Blue
Low-Battery	Flash in red
Charging	Steady red, off after fully charged

Basic Key Operation

Power On

Press and hold  for 3 seconds to power on. Indicator will flash in red and blue.

Power Off

Press and hold  for 3 seconds to power off.

Volume Control


Rolling the button  to volume up,  to volume down.

Songs Track

Click  twice for next track.

Click  3 times for previous track.


Multifunction Button

Click  for music pause.

Click  for music play.

Click  to accept a call.

Click  to hang up a call.

Click  twice to reject a call.

Mute/Activate Microphone

1. Click "M" to mute the microphone, the indicator will go off with voice broadcast.

2. Click "M" Again to activate the microphone with a voice broadcast.

Headphone Charging

Please charge the headset for about 2 hours at low-battery status, while charging, the headset default to power off. indicator steady red and go off after fully charged.

Battery Status

When connected with an IOS device, the battery status will show on the upper right corner of the screen.

Line-in Mode

After plugging the aux cable into the headset, it will default to power off. Microphone still available.

Noye: Headset could not be turned on with aux cable in.

Wireless Mode

Powering on the headset, the indicator will flash in red and blue. Open the wireless feature and search the device named "BG-01", click the name to complete connection.

Delete Pairing Information

Hold and press the "power" button and "M" to delete the pairing information on the headset.

Headphone Appearance Wireframe



picun

Automatic shutdown and over-distance reconnection

Headphones will reconnect to the phones when it comes back to effective distance within 5 minutes, or turn off after 5 minutes.

Product parameter

Wireless Version	Bluetooth V5.3
Wireless Protocol	A2DP/AVRCP/SMP/HFP
Effective Distance	10 meters
Speaker Impedance	32Ω±15%
Sensitivity	98±3dB at 1K HZ
Frequency Range	20 HZ---20K HZ
Charging Voltage	DC5V
Recharging Current	180mA
Operating Voltage	3.7V
Operating Current	12-25mA

picun

What's in the box

1. Wireless Headphone	3. Audio cable
2. User Manual	4. Charging Cable

Notes:

1. Use a 5V1A/5V2A charger to charge the headset. Charging the headset with a charging device with a high voltage may damage it.
2. When the headset has not been used for more than 3 months, it is necessary to charge the headset before using it.
3. When not in use for a long time, it is recommended to charge the headset every 3 months, which can more effectively protect the Protect battery usage.
4. It is recommended to use the earphones after they are fully charged.

Attentions:

- *Do not place the headset in a high temperature environment, including direct sunlight.
- *Do not place the headset near a fire or other overheating environment.
- *Do not place the earphones in damp or submerged in liquid, keep the earphones dry.
- *Do not attempt to charge the headset by any method other than the supplied charging cable.

picun

*Do not disassemble the earphones, and any attempt to repair or modify the earphones is prohibited.

*Please pay attention to excessive drops, impacts, scratches or other behaviors that affect the function of the headset, if there is any damage, such as dents, punctures, tear deformation or corrosion, etc., please stop using the headset equipment immediately, and contact the purchaser or Contact us via the contact details on the warranty card.

*If the earphones produce abnormal smell, higher than normal temperature, abnormal changes in color or shape, please stop using the earphones immediately, and contact the merchant you purchased or contact us through the contact information on the warranty card.

Warnings:

*Using headphones at high volume for a long time may cause damage to your hearing.

WARRANTY CARD

Product Model:	Product Color:
Purchase Date:	Purchase Store:
Purchase Account:	Reason for Warranty:
User Name:	Phone Number:
User Address:	

Warranty Description

Please keep the warranty card and valid purchase proof properly, show it together when sending the product to repair. If you can't provide the warranty card or relevant purchase certificate, the calculation date of the product warranty will be based on the product manufacture date.

Warranty Regulations

1. If you have any questions during using, please don't hesitate to call 4008894883 for help.
2. Within one year from the purchase date, if the product with quality issue and the technical staff of our company has confirmed that the issue occurs under normal use, we will provide free replacement services.
3. In the following cases, our company refuses to provide free warranty service, only provides maintenance services, free of labor costs, only charges for parts:
 - A. The product main part has been damaged due to incorrect operation, negligent use or irresistible reasons
 - B. The product has been dismantled or repaired without our company authorization
 - C. The headphone driver unit has been used at high volume, and the diaphragm is deformed due to debris or impact. The headphone cable is broken, crushed, immersed in water, the case is damaged, deformed, and some other man-made damage reason.
 - D. The original warranty card and valid purchase proof can't be provided, and the purchase date is beyond the warranty period.
4. The free service provided by this warranty card does not include product accessories, and other decorations, gift, etc.

Product Qualification Certificate
After inspection, the product
meets the technical standards
and is allowed to leave the factory.

QC 08
PASS