


TRAVELHAWK POWERBANK

10000 mAh User Manual

Read this user manual carefully
before you using the power bank

Detail Instruction




- ① USB 1 Output Port
- ② USB 2 Output Port
- ③ Type-C Input/Output Port
- ④ LED Indicators
- ⑤ Button
- ⑥ Micro USB Input Port

Charge The Power Bank



- ① Use suitable cable to connect the Micro USB/Type-C port of the power bank with charger to charge the power bank.
- ② Use suitable cable to connect the Micro USB/Type-C port of the power bank with computer /laptop to charge the power bank.

Output



- ① Have 2 USB & Type-C output port of the power bank. Use suitable cable to connect your devices with power bank to charge.

LED indicators

	75%-100%
	50%-75%
	25%-50%
	0-25%

Specifications

Battery type: Li-Polymer
Battery capacity: 10000mAh (37Wh)3.7V
Input: Micro USB/Type-C 5V/2A
Output: Double USB/Type-C 5V/2.1A
Charging time: about 5 Hours
Size: 136*70*14.5mm
Weight: 193g

Warning

- Do not expose charger to extreme temperatures or moist environments.
- Keep away from liquids; store in dry areas.
- Keep away from children.
- Do not disassemble or apply excessive pressure.
- Do not use charger with any device outside the mentioned output parameters.

