



#### Use

1. Place the footstuff you wish to process into the glass jug.
2. Put the lid on the glass jug and close securely. Place the measuring cup into the hole in the lid and turn clockwise to lock.
3. Switch on the motor block.

#### Speed Setting Use

- |           |  |
|-----------|--|
| 1 setting | for light usage with liquids   |
| 2 setting | for more solid consistency - for mixing liquids and solid ingredients  |
| 3 setting | for ice crushing & short, powerful impulsive movements (The switch does not permanently engage in the '3' setting. You have to hold the switch in the '3' setting or turn it repeatedly into the '3' setting.) |

After using the blender, always move the switch into the '0' setting and pull out the main plug.

To remove the glass jug just lift it up. You do not have to release the glass jug to remove it.

#### Useful tips

- To achieve the best results when processing solid ingredients, place small portions into the glass jug and by one instead of placing a large quantity all at once.
- If you are processing solid ingredients, cut them into small pieces (2-3cm) first.
- When mixing solid ingredients start off first with a small amount of liquid. Gradually add more and more liquid through the opening in the lid.
- Always check your hand on top of the blender when you are operating the device.
- Be careful when processing hot liquids.
- For stirring solid or very thick liquid ingredients we recommend that you use the blender in impulse mode to prevent the blades from becoming stuck.
- Recommendation to blend mixture of particles  
As this appliance has higher power than common blenders, it takes shorter period to blend food. For example, this appliance operates at max power with mixture of 480g particles + 720g water in the speed setting 2.
- Maximum operating time is 2 minutes of each use then the appliance to cool down to ambient temperature after each use.

#### Dry mill



#### CAUTION:

- \* Maximum capacity 80g
- \* Not use with wet ingredients or liquids.
- \* Do not operate more than 60 seconds at one time.

#### Simple clearing/rinsing out the assembled glass jug

Empty the glass jug and fill with water. Place the glass jug on the motor block and turn the switch several times into the '3' setting. Empty the glass jug and rinse until clean.

#### Thorough clearing of the dismantled glass jug

Never immerse the motor block in water. Wipe it only with a moist cloth.

Thorough clearing of the dismantled glass jug: ensure that the glass jug is completely empty before you unplug the measuring ring. Be careful when handling the cutting blades. All removable parts are suitable for the dishwasher. We reserve the right to make amendments.