

Scene Switch

-Remote control
-Off-Line Control Support
-Mechanical Push Button with LED feedback

V2.0 A

Scene Switch

Product Introduction

- The smart scene switch is based on ZigBee/BLE MESH technology, with stable network, fast response, high security, strong expansion ability, and low power consumption.
- The ZigBee/BLE MESH smart scene switch can be used with other smart devices to realize rich home automation and scene control.

Specification

Battery:	CR2430 3V DC
Communication:	ZigBee 3.0 / BLE MESH
Dimension:	86*86*13mm
Working Range:	25m open area
Working Temperature:	-10°C-45°C
Working Humidity:	<90%RH
Battery Life:	50000 times

Please use it with the corresponding gateway to get the best experience

Scene Switch

Quick Configure Mode

Press and hold the switch button 1 for 10s until indicate LED flash, the switch get into Quick Configure Mode

Scene Switch

Scene Switch with Your Smart Home

Scene Switch

Connection and Operation

Scene Switch

Install/Replace Battery

Please follow this instruction to install battery or remove battery tap when first time use this product.

1. Push the front panel to the left to open
2. Remove old battery then push new CR2430 battery to slot.

After replacing the battery, the smart scene switch will automatically connect to the ZigBee/BLE MESH network and resume normal working status, and the user does not need to make any APP settings.

Scene Switch

Fix it as Where as You Want

Scene Switch

APP Operation

1. Download the app
Scan QR code and download the app iOS / Android version

Scene Switch

3.Add Devices

Ensure ZigBee/BLE MESH gateway is online before adding devices

Press and hold the **Reset** button get the device into the quick configuration mode. Open the Smart life app, on the "smart gateway" page, click "add subdevice", and follow app instruction to complete operation.

Scene Switch

After connecting the network successfully, you will see the Intelligent Gateway page, choose the WIRELESS SWITCH 2 to enter the controlling page, then choose "Add intelligence" enter to the setting mode.

Scene Switch

Select the device and action

Scene Switch

Reset

Press and hold **Reset** button for 10s to reset the switch and get into Quick configure mode.

2.Register and login

The user needs to register the user first, and can use the mobile phone number to register.
Once you are done, you can use this username to log in to the APP and proceed to the next step.
*Support some third-party accounts are directly logged in

Wait for device searching for 1-3min, Click "DONE" to complete the process.
*NOTE: If you fail to add the device, please move the gateway closer to get better signal.

Choose "Add condition" to choose the the controlling condition, such as "Single click", the choose "Add task" choose the controlling action.

Save your collocation, then you could use the scene switch to control the light.

Hihome

www.hihome.eu