

...automatisch 6 uur  
... "ON" voor continue uit  
... Le combi de cet ensemble  
... il le combi est automatique  
... Les lampes ne peuvent pas être  
... Cette guirlande n'est pas un jouet, elle sera de grande utilité  
... 1 "TIMER" pour allumer  
... pendant 18 heures; 2 "ON" pour allumer en  
... continu.

... Das flexible Kabel dieses  
... nicht eingetauscht werden, wenn das Kabel  
... das Beleuchtungsnetz zu betriebsfähig. Die Lampen können  
... werden. Diese Lichtkette ist kein Kinderspielzeug  
... anbringen. Dieses Beleuchtungsnetz hat 3  
... 1 „ON“ = Dauerbetrieb; 2 „TIMER“ = automatisch 6 St. an  
... 18 St. aus; 3 „OFF“ = dauerhaft aus.

**EN** - for indoor use only. The external flexible cable or cord of this  
luminaire cannot be replaced; if the cord is damaged, the luminaire shall  
be destroyed. The lamps are not replaceable. This lighting chain is no  
toy - please keep it inaccessible for children. This light set has 3 functions:  
1. "ON" for continuously switched on; 2. "TIMER" for switching the light out  
off automatically (6 hours on and 18 hours off); 3. "OFF" for continuously  
switched off.




Itemnr.: 228121

Battery operated



2x AA (Not included)



MADE IN P.R.C.

COEN BAKKER DECO  
SMEETSWEG 4, 1738 DK WAARLAND (NL)