



HOW TO SET TIME

1




SCREW OFF THE COVER OF THE BATTERY COMPARTMENT

2




PLACE TWO AAA BATTERIES AND SCREW BACK THE BATTERY COVER

3



TURN THE CLOCK TO "HOME TIME ZONE"



4

HOLD BUTTON "SET" FOR 2 SECONDS, CLOCK WILL TURN ON SETTING MODE FOR DATE AND TIME

5

PRESS BUTTON ↑ TO ADJUST THE VALUE

6

PRESS BUTTON "SET" TO CHANGE THE SEQUENCE



The clock uses UTC standard and 24hrs mode. To select the correct time zone for the "Home Time Zone" set the time zone.

For example, +8 for Hong Kong, +1 for Amsterdam and -5 for New York time zone.

- The number will be blinking to show what you are setting.
- The sequence of setting mode, is year, month, day, hour, minute, time difference and exit.
- Set only the time and date in "Home Time Zone".
- The background light will last 2 seconds when a button pressed.

