



GSX 1200 Pro

Headset Amplifier

User Guide
Bedienungsanleitung
Notice d'emploi
Istruzioni per l'uso
Instrucciones de uso
Manual de instruções
Bedieningsinstructies

Οδηγίες λειτουργίας
Betjeningsvejledning
Bruksanvisning
Käyttöohje
Instrukcja obsługi
Инструкция по
эксплуатации

使用说明书
使用説明書
Kullanım kılavuzu
取扱説明書
Buku petunjuk
사용 설명서

Chapter overview

1 Scope of delivery

Lieferumfang | Contenu | Dotazione | Volumen de suministro | Material fornecido | Omvang van de levering | Συσκευασία παράδοσης | Leveringsomfang | Medföljande delar | Toimitussisältö | Zakres dostawy | Комплект поставки | 供货范围 | 供货範圍 | Teslimat kapsamı | 同梱品 | Isi kemasan | 구성품

2 Product overview

Produktübersicht | Vue d'ensemble de l'appareil | Panoramica del prodotto | Vista general del producto | Vista geral do produto | Productoverzicht | Συνοπτική παρουσίαση προϊόντος | Produktoversigt | Produktöversikt | Tuotteen yleiskatsaus | Przegląd produktów | Общий вид изделия | 产品总览 | 產品各部件簡介 | Ürüne Genel Bakış | 製品概要 | Ikhtisar Produk | 제품 개요

3 Connecting the product

Produkt anschließen | Raccordement de l'appareil | Collegamento del prodotto | Conectar el producto | Ligar o produto | Product aansluiten | Σύνδεση προϊόντος | Tilslutning af produktet | Anslut produkten | Liitä tuote | Podłączenie produktu | Подключение изделия | 连接产品 | 連接產品 | Ürünün bağlanması | 製品の接続 | Menyambungkan produk | 제품 연결

4 Installing the product

Produkt installieren | Installation de l'appareil | Installazione del prodotto | Instalar el producto | Instalar o produto | Product installeren | Εγκατάσταση προϊόντος | Installation af produktet | Installera produkten | Asenna tuote | Instalowanie produktu | Установка изделия | 安装产品 | 安裝產品 | Ürünün kurulumu | 製品のインストール | Menginstal produk | 제품 설치

5 Changing settings

Einstellungen ändern | Modification des paramètres | Modifica delle impostazioni | Modificar los ajustes | Alterar definições | Instellingen wijzigen | Αλλαγή ρυθμίσεων | Ændring af indstillinger | Ändra inställningarna | Muuta asetuksia | Zmiana ustawień | Изменение настроек | 更改设置 | 變更設定 | Ayarların değiştirilmesi | 設定の変更 | Mengubah pengaturan | 설정 변경

6 Saving & loading settings

Einstellungen speichern & laden | Sauvegarde et chargement des paramètres | Memorizzazione e caricamento delle impostazioni | Guardar e cargar ajustes | Guardar e carregar definições | Instellingen opslaan & laden | Αποθήκευση και φόρτωση ρυθμίσεων | Lagring og indlæsning af indstillinger | Spara & hämta inställningar | Tallenna ja lataa asetukset | Zapisywanie i ładowanie ustawień | Сохранение и загрузка настроек | 保存并加载设置 | 儲存並載入設定 | Ayarların kaydedilmesi ve yüklenmesi | 設定の保存と呼び出し | Menyimpan & memuat pengaturan | 설정 저장 & 불러오기

7 Cleaning the product

Produkt reinigen | Nettoyage de l'appareil | Pulizia del prodotto | Limpiar el producto | Limpar o produto | Product reinigen | Καθαρισμός προϊόντος | Rengøring af produktet | Rengör produkten | Puhdista tuote | Czystczenie produktu | Очистка изделия | 清洁产品 | 清潔產品 | Ürünün temizlenmesi | 製品のお手入れ | Membersihkan produk | 제품 청소

8 Restoring factory settings

Auf Werkseinstellungen zurücksetzen | Réinitialisation des paramètres d'usine | Ripristino delle impostazioni di fabbrica | Restablecer los ajustes de fábrica | Repor as definições de fábrica | Resetten op fabrieksinstellingen | Επαναφορά εργοστασιακών ρυθμίσεων | Tilbagestilling til fabriksindstillinger | Återställ till fabriksinställningarna | Palauta tehdasasetukset | Przywracanie ustawień domyślnych | Сброс на заводские настройки | 恢复出厂设置 | 恢復出廠預設值 | Varsayılan fabrika ayarlarının geri yüklenmesi | 工場出荷時の初期設定にリセットする | Mengatur ulang pengaturan default pabrik | 공장 설정값으로 리셋하기

Congratulations on your purchase of the Sennheiser GSX 1200 Pro. Sennheiser has been a pioneer in the audio industry since 1945, and we continue to innovate and discover new frontiers in sound. The GSX 1200 Pro is the latest milestone in this journey, pushing the limits of immersive audio in gaming, while also giving you control to get the exact sound experience you demand.

The Sennheiser Virtual Surround algorithm is the result of 8 years of research into advanced HRTF algorithms and countless man hours to create something that we consider the best virtual surround sound on the market today.

It doesn't matter if your goal is to become more immersed in online worlds, or get a crucial advantage in a first person shooter, the GSX 1200 Pro will deliver the ultimate sound experience for gaming.




And while the GSX 1200 Pro is very simple to setup and there are no driver installations needed, we still recommend you take a bit of time to read through this manual to understand the full power of the product you have just acquired.

**Sennheiser Gaming
The Sound Games
Are Made Of!**




Chapter overview | Kapitelübersicht | Sommaire |
Panoramica dei capitoli | Vista general de capítulos | Visão geral dos capítulos |
Overzicht hoofdstukken | Εποκόπηση κεφαλαίων | Kapiteloversigt |
Innehållsförteckning | Kappaleen yleiskuvaus | Przegląd rozdziałów |
Оглавление | 章节概览 | 章節概覽 | Bölümlere genel bakış |
目次 | Ikhtisar Bab | 장 개요


1 Scope of delivery



back side



right side



left side

Scope of delivery | Lieferumfang | Contenu |
Dotazione | Volumen de suministro | Material fornecido |
Omvang van de levering | Συσκευασία παράδοσης | Leveringsomfang |
Medföljande delar | Toimitussisältö | Zakres dostawy |
Комплект поставки | 供货范围 | 供貨範圍 | Teslimat kapsamı |
同梱品 | Isi kemasan | 구성품

Volume wheel

Save settings & load presets

Display & Touch control panel



48

Volume 0–99




Switch between sound systems:
Headset or Speaker




2.0 HD
7.1






4 Installing the product


Change audio settings: PC




1. Right-click the Audio icon.



2. Select "Playback devices".




3. Select "Speakers"
"GSX ... Main Audio".




4. Select "Default Device".

Changing the sound settings on a PC | Audioeinstellungen am PC anpassen | Réglage des paramètres audio du PC | Adattamento delle impostazioni audio sul PC | Ajustar los ajustes de audio en el PC | Ajustar as definições de áudio no PC | Audio-instellingen op de pc aanpassen | Προσαρμογή των ρυθμίσεων ήχου σε PC | Tilpasning af audioindstillinger på en pc | Justera ljudinställningarna på datorn | Säädä tietokoneen audioasetukset | Dostosowywanie ustawień audio na komputerze PC | Адаптація налаштувань звуку на ПК | 调整电脑的音频设置 | 調整電腦的音訊設定 | Bilgisayarda ses ayarlarının uyarlanması | オーディオ設定のPCでの変更 | Menyesuaikan pengaturan audio pada PC | PC에서 오디오-설정 조정


4 Installing the product




5. Select "Headset Earphone"
"GSX ... Communication Audio".



6. Select
"Default Communication Device".




7. Select tab "Recording".




8. Select "GSX ... Communication Audio".

Changing the sound settings on a PC | Audioeinstellungen am PC anpassen | Réglage des paramètres audio du PC | Adattamento delle impostazioni audio sul PC | Ajustar los ajustes de audio en el PC | Ajustar as definições de áudio no PC | Audio-instellingen op de pc aanpassen | Προσαρμογή των ρυθμίσεων ήχου σε PC | Tilpasning af audioindstillinger på en pc | Justera ljudinställningarna på datorn | Säädä tietokoneen audioasetukset | Dostosowywanie ustawień audio na komputerze PC | Адаптация настроек звука на ПК | 调整电脑的音频设置 | 調整電腦的音訊設定 | Bilgisayarda ses ayarlarının uyarlanması | オーディオ設定のPCでの変更 | Menyesuaikan pengaturan audio pada PC | PC에서 오디오-설정 조정

4 Installing the product




9. Select "Default Device".




10. Select tab "Communications".
11. Select "Do nothing".

7.1 surround sound




12. Select tab "Playback".




13. Select Speakers "GSX ... Main Audio".
14. Click "Configure".

Changing the sound settings on a PC | Audioeinstellungen am PC anpassen | Réglage des paramètres audio du PC |
Adattamento delle impostazioni audio sul PC | Ajustar los ajustes de audio en el PC | Ajustar as definições de áudio no PC |
Audio-instellingen op de pc aanpassen | Προσαρμογή των ρυθμίσεων ήχου σε PC | Tilpasning af audioindstillinger på en pc |
Justera ljudinställningarna på datorn | Säädä tietokoneen audioasetukset | Dostosowywanie ustawień audio na komputerze PC |
Адаптация настроек звука на ПК | 调整电脑的音频设置 | 調整電腦的音訊設定 | Bilgisayarda ses ayarlarının uyarlanması |
オーディオ設定のPCでの変更 | Menyesuaikan pengaturan audio pada PC | PC에서 오디오-설정 조정


4 Installing the product



15. Select "7.1 Surround" and click "Next".



16. Make sure all options are activated and click "Next".



17. Activate all options and click "Next" to close "Speaker Setup".
18. Click "OK" to save settings and close the window.




For specific information and
Firmware update please visit
www.sennheiser.com/gaming-downloads




Changing the sound settings on a PC | Audioeinstellungen am PC anpassen | Réglage des paramètres audio du PC |
Adattamento delle impostazioni audio sul PC | Ajustar los ajustes de audio en el PC | Ajustar as definições de áudio no PC |
Audio-instellingen op de pc aanpassen | Προσαρμογή των ρυθμίσεων ήχου σε PC | Tilpasning af audioindstillinger på en pc |
Justera ljudinställningarna på datorn | Säädä tietokoneen audioasetukset | Dostosowywanie ustawień audio na komputerze PC |
Адаптація налаштувань звуку на ПК | 调整电脑的音频设置 | 調整電腦的音訊設定 | Bilgisayarda ses ayarlarının uyarlanması |
オーディオ設定のPCでの変更 | Menyesuaikan pengaturan audio pada PC | PC에서 오디오-설정 조정


Change audio settings: Mac




1. Click the Apple icon.



2. Select "System Preferences...".



3. Select "Sound".




4. Select tab "Output".


Changing the sound settings on a Mac | Audioeinstellungen am Mac anpassen | Réglage des paramètres audio du Mac | Adattamento delle impostazioni audio sul Mac | Ajustar los ajustes de audio en Mac | Ajustar as definições de áudio num Mac | Audio-instellingen op de Mac aanpassen | Προσαρμογή των ρυθμίσεων ήχου σε Mac | Tilpasning af audioindstillinger på en mac | Justera ljudinställningarna på Mac-dator | Säädä Mac-tietokoneen audioasetukset | Dostosowywanie ustawień audio na komputerze Mac | Адаптація налаштувань звуку на Mac | 调整Mac的音频设置 | 調整 Mac 的音訊設定 | Mac'te ses ayarlarının uyarlanması | オーディオ設定のMacでの変更 | Menyesuaikan pengaturan audio pada Mac | Mac에서 오디오-설정 조정

4 Installing the product


Change audio settings: Mac




5. Select "GSX ... Communication Audio".



6. Select tab "Input".




7. Select "GSX... Communication Audio" and close the settings.




8. Enter "audio" in the "Finder" and select "Audio MIDI Setup" application.

Changing the sound settings on a Mac | Audioeinstellungen am Mac anpassen | Réglage des paramètres audio du Mac | Adattamento delle impostazioni audio sul Mac | Ajustar los ajustes de audio en Mac | Ajustar as definições de áudio num Mac | Audio-instellingen op de Mac aanpassen | Προσαρμογή των ρυθμίσεων ήχου σε Mac | Tilpasning af audioindstillinger på en mac | Justera ljudinställningarna på Mac-dator | Säädä Mac-tietokoneen audioasetukset | Dostosowywanie ustawień audio na komputerze Mac | Адаптація настроек звука на Mac | 调整Mac的音频设置 | 調整 Mac 的音訊設定 | Mac'te ses ayarlarının uyarlanması | オーディオ設定のMac での変更 | Menyesuaikan pengaturan audio pada Mac | Mac에서 오디오-설정 조정


Change audio settings: Mac




9. Select tab "Output".



10. Select "8ch-16bit Integer" from the drop down menu.




11. Click "Configure speakers".




12. Select tab "Multichannel".


Changing the sound settings on a Mac | Audioeinstellungen am Mac anpassen | Réglage des paramètres audio du Mac | Adattamento delle impostazioni audio sul Mac | Ajustar los ajustes de audio en Mac | Ajustar as definições de áudio num Mac | Audio-instellingen op de Mac aanpassen | Προσαρμογή των ρυθμίσεων ήχου σε Mac | Tilpasning af audioindstillinger på en mac | Justera ljudinställningarna på Mac-dator | Säädä Mac-tietokoneen audioasetukset | Dostosowywanie ustawień audio na komputerze Mac | Адаптація настроек звука на Mac | 调整Mac的音频设置 | 調整 Mac 的音訊設定 | Mac'te ses ayarlarının uyarlanması | オーディオ設定のMac での変更 | Menyesuaikan pengaturan audio pada Mac | Mac에서 오디오-설정 조정


Change audio settings: Mac



13. Select "7.1 Surround" from the drop down menu.



14. Click "Apply" to close the window. 







For specific information and Firmware update please visit www.sennheiser.com/gaming-downloads




Changing the sound settings on a Mac | Audioeinstellungen am Mac anpassen | Réglage des paramètres audio du Mac | Adattamento delle impostazioni audio sul Mac | Ajustar los ajustes de audio en Mac | Ajustar as definições de áudio num Mac | Audio-instellingen op de Mac aanpassen | Προσαρμογή των ρυθμίσεων ήχου σε Mac | Tilpasning af audioindstillinger på en mac | Justera ljudinställningarna på Mac-dator | Säädä Mac-tietokoneen audioasetukset | Dostosowywanie ustawień audio na komputerze Mac | Адаптація настроек звука на Mac | 调整Mac的音频设置 | 調整 Mac 的音訊設定 | Mac'te ses ayarlarının uyarlanması | オーディオ設定のMacでの変更 | Menyesuaikan pengaturan audio pada Mac | Mac에서 오디오-설정 조정

5 Changing settings







Changing the volume via volume wheel or via your computer | Laustärke über „Volume wheel“ oder Computer einstellen | Réglage du volume via la commande du volume ou sur l'ordinateur | Impostazione del volume attraverso l'apposita manopola o il computer | Ajustar el volumen mediante "Volume wheel" u ordenador | Definir o volume através do botão regulador do volume ou do computador | Geluidssterkte via „Volume wheel“ of computer instellen | Ρύθμιση έντασης ήχου μέσω του τροχού έντασης ή του υπολογιστή | Indstilling af lydstyrken via „volume wheel“ eller computer | J usterar volymen via „Volume wheel“ eller via datorn | Säädä äänenvoimakkuus "volume wheel":n tai tietokoneen välityksellä | Regulacja głośności za pomocą pokrętki „Volume“ lub komputera | Регулировка громкости с помощью колесика или на компьютере | 通过“音量旋钮”或电脑设置音量 | 通過「音量旋鈕」或電腦設定音量 | "Volume wheel" veya bilgisayar üzerinden ses seviyesinin ayarlanması | 「ボリューム・ホイール」またはPCでのボリュームの調節 | Mengatur volume melalui "tombol Volume" atau komputer | "Volume wheel(소리 조절기)" 또는 컴퓨터로 볼륨 설정

come close to activate the screen



Activating the screen | Anzeige aktivieren | Activation de l'affichage |
Attivazione della visualizzazione | Activar la pantalla | Ativar o ecrã |
Weergave activeren | Ενεργοποίηση της οθόνης | Aktivering af visningen |
Aktivera displayen | Aktivoi näyttö | Aktywacja ekranu |
Активация экрана | 激活显示屏 | 啟動顯示幕 | Göstergenin etkinleştirilmesi |
表示の有効化 | Mengaktifkan indikator | 표시 활성화


touch the loudspeaker icon



only equalizer settings available

Switching between headset & speakers | Zwischen Headset und Lautsprechern umschalten | Commutation entre le casque micro et les haut-parleurs
Commutazione tra headset e altoparlanti | Conmutar entre el headset y los altavoces | Comutar entre os microauscultadores e as colunas |
Tussen headset en luidsprekers omschakelen | Εναλλαγή μεταξύ σετ κεφαλής και ηχείων | Omstilling mellem headset og højttalere |
Växla mellan headsetet och högtalare | Vaihda kytkentä kuulokemikrofonin ja kaiuttimien välillä | Przełączenie między zestawem słuchaw-
kowym i głośnikami | Переключение между гарнитурой и динамиками | 在耳机与扬声器之间切换 | 在頭戴式耳機和揚聲器之間進行切換 | Kulaklık
ve hoparlörler arasında geçiş yapma | ヘッドセットとスピーカーの切り替え | Beralih antara headset dan loudspeaker | 헤드셋 및 스피커 전환

touch the equalizer icon



Esport



Music



Story





No equalizer



Choosing equalizer settings | Equalizer-Einstellungen wählen | Sélection des paramètres de l'égaliseur | Selezione delle impostazioni dell'equalizzatore | Seleccionar los ajustes del equalizador | Selecionar as definições do equalizador | Equalizer-instellingen selecteren | Επιλογή ρυθμίσεων του ισοσταθμιστή | Valg af equalizer-indstillinger | Välj equalizerinställningar | Valitse Equalizer-asetukset | Wybór ustawień equalizera | Выбор настроек эквалайзера | 选择均衡器设置 | 選擇均衡器設定 | Ekolayzer ayarlarının seçilmesi | イコライザー設定の選択 | Memilih pengaturan equalizer | 이퀄라이저-설정 선택


touch the sound focus icon



Increase virtual FRONT speakers



Increase virtual BACK speakers





balanced sound volume



Changing amplification focus to front or rear | virtuelle Verstärkung vorn oder hinten einstellen | Réglage de l'amplification virtuelle avant et arrière
Impostazione dell'amplificazione virtuale davanti o dietro | Ajustar la ganancia virtual delantera o posterior | Definir a amplificação virtual à frente ou atrás | virtuele versterking voor of achter instellen | ρύθμιση εικονικής ενίσχυσης εμπρός ή πίσω | Indstilling af virtuel forstærkning forfra eller bagfra | Justera virtuell förstärkning fram och bak | Säädä virtuaalinen voimakkuus edestä tai takaa | Regulacja wzmacnienia wirtualnego z przodu lub z tyłu | Настройка виртуального усиления спереди или сзади | 设置前方或后方虚拟增益 | 設定前方或後方的虛擬增益 | Ön veya arka sanal amplifikasyonun ayarlanması | 前後の仮想ボリュームの設定 | Mengatur amplifier virtual depan atau belakang | 전방 및 후방 가상 증폭 설정

touch the audio icon




For movies and games supporting 7.1 and 5.1 surround sound.



CAUTION!
Hearing damage due to high volumes!
This mode provides a higher volume level.
Reduce the volume level via the product or via your computer to avoid hearing damage.




24 Bit/96 kHz audio:
HD will be activated if 24 bit is set ON in Windows. Not all settings are available.



Choosing stereo or 7.1 virtual surround sound | Stereo oder 7.1 virtuellen Raumklang wählen | Sélection du relief acoustique stéréo ou 7.1 | Selezione di stereo o di suono stereofonico virtuale 7.1 | Seleccionar estéreo o sonido envolvente virtual 7.1 | Seleccionar o som surround estéreo ou surround virtual 7.1 | Stereo of 7.1 virtueel ruimtelijk geluid selecteren | Επιλογή ήχου stereo ή ήχου virtual surround 7.1 | Valg af stereo eller 7.1 virtuel rumklang | Välj stereo eller 7.1 virtuell rumsligt ljud | Valitse stereo tai 7.1 virtuaalinen tilaääni | Wybór stereo lub wirtualnego dźwięku przestrzennego 7.1 | Выбор стерео или виртуального объемного звучания 7.1 | 选择立体声或7.1虚拟立体声 | 選擇立體聲或7.1虛擬立體聲 | Stereo veya 7.1 sanal çevresel sesin seçilmesi | ステレオまたは7.1仮想立体音響の選択 | Memilih stereo atau suara surround virtual 7.1 | 스테레오 또는 7.1 가상 입체 음향 선택

touch the headset icon



no sidetone



+ for low sidetone

Recommended for open back headsets and some on-ear headsets.





++ for high sidetone


Recommended for closed back around-ear or in-ear headsets.

Adjusting the sidetone | Mithörton anpassen | Réglage du son d'écoute |
Adattamento dell'audio di ascolto | Ajustar el sidetone | Ajustar o tom lateral |
Meeluistergeluid aanpassen | Ρύθμιση πλευρικού τόνου | Tilpasning af medhørstone |
Justera ljudet för medlyssning | Säädä sivuääni | Regulacja funkcji podłuchu |
Изменение громкости посторонних звуков | 調整側音 | 調整側音 | Birlikte dinleme sesinin uyarlanması |
側音の調節 | Menyesuaikan nada samping | 축음 조정


touch the environment icon



environment
for super accurate sound
Recommended for highest accuracy in sound reproduction.




environment
+ for confined space
Recommended for semi open world games.




environment
++ for open world
Recommended for open world games.



Changing reverb (environments) | Halleffekt (Umgebung) anpassen | Réglage de l'effet hall (ambiance) | Adattamento effetto Hall (ambiente) | Ajustar el efecto Hall (entorno) | Ajustar o efeito de reverberação (ambiente) | Haleffect (omgeving) aanpassen | Ρύθμιση εφέ αντήχησης (περιβάλλον) | Tilpasning af Hall-effekten (omgivelser) | Justera ekoeffekten (omgivning) | Säädä kaiku (ympäristö) | Dopasowywanie pogłosu (otoczenie) | Изменение пространственного эффекта (среды) | 调整霍尔效应 (环境) | 調整霍爾效應 (環境) | Hall etkisinin (çevre) uyarlanması | エコー効果 (周辺) の変更 | Menyesuaikan efek echo (lingkungan) | 홀 효과(주변) 조정




touch & hold one button to save the settings as preset




Saving settings as a preset: up to 4 - one in each corner | Einstellungen als Vorgabe speichern: bis zu 4 - eine in jeder Ecke | Sauvegarde des paramètres consignés : jusqu'à 4 - un dans chaque angle | Memorizzazione delle impostazioni come predefinite: fino a 4 - una in ogni angolo | Guardar los ajustes como predefinidos: hasta 4 - uno en cada esquina | Guardar definições como predefinição: até 4 - uma em cada canto | Instellingen als vastgelegde waarde opslaan: max. 4 - één in elke hoek | Αποθήκευση ρυθμίσεων ως προεπιλογή: μέχρι 4 - μία σε κάθε γωνία | Lagring af indstillinger som forlæg: op til 4 - en i hvert hjørne | Spara inställningar som förval: upp till 4 - en i varje hörn | Tallenna asetukset oletukseksi: enintään neljään - yksi jokaisessa nurkassa | Zapisz ustawień jako wartość zadana: maks. 4 - dla każdego rogu | Сохранение настроек для последующего использования: до 4 — одна в каждом углу | 将设置保存为规定参数: 最多为4个 - 每个角一个 | 將設定儲存為規定參數: 最多為4個 - 每個角一個 | Ayarların varsayılan olarak kaydedilmesi: en fazla 4 - her köşede bir adet | 設定をデフォルトとして保存: 4件まで、各コーナーで1件ずつ | Menyimpan pengaturan sebagai default: hingga 4 - satu di setiap sudut | 설정을 표준으로 저장: 각 코너에 하나씩 최대 4개

touch one button to load the preset




example: preset 4



example: preset 1




example: preset 2




example: preset 3


change settings: all presets red



Loading one of your 4 presets | Eine Deiner 4 Voreinstellungen (preset) laden | Chargement d'une de tes 4 présélections (preset) | Caricamento di una delle 4 preimpostazioni personali (preset) | Cargar uno de los 4 preajustes (preset) | Carregar uma das tuas 4 predefinições | Eén van je 4 vooraf ingestelde instellingen (preset) laden | Φόρτωση μίας εκ των 4 προεπιλεγμένων ρυθμίσεων (preset) | Indlæsning af en af dine 4 forindstillinger (preset) | Hämta en av dina 4 förvalda (preset) inställningar | Lataa yksi neljästä esiasetuksestasi (preset) | ładowanie jednego z 4 ustawień wstępnych (preset) | Загрузка одной из 4 предварительных настроек (пресетов) | 加载4个预设中的一个 | 載入 4 個預設的其中一個 | 4 ön ayarından (preset) birini yükleme | 保存した 4 つの設定 (プリセット) のうちの 1 つを読み込む | Memuat 4 preset Anda | 4개 사전 설정(프리셋) 중 1개 불러오기



touch all preset buttons to reset



Restoring factory settings | Auf Werkseinstellungen zurücksetzen | Réinitialisation des paramètres d'usine | Ripristino delle impostazioni di fabbrica | Restablecer los ajustes de fábrica | Repor as definições de fábrica | Resetten op fabrieksinstellingen | Επαναφορά εργοστασιακών ρυθμίσεων | Tilbagesstilling til fabriksindstillinger | Återställ till fabriksinställningarna | Palauta tehdasasetukset | Przywrócenie ustawień domyślnych | Сброс на заводские настройки | 恢复出厂设置 | 恢復出廠預設值 | Varsayılan fabrika ayarlarının geri yüklenmesi | 工場出荷時の初期設定にリセットする | Mengatur ulang pengaturan default pabrik | 공장 설정값으로 리셋하기



Sennheiser Communications A/S
Industriparken 27, DK-2750, Denmark
www.sennheiser.com

Publ. 06/16, A01