

NL: Artikel is alleen geschikt voor
doeleinden. Artikel is geen speelgoed, bewaaren bereik
van kinderen houden. Bewaar deze informatie zorgvuldig.
Deze verlichtingsset heeft 3 functies: 1. "TIMER" voor automa-
tisch 6 uur aan en 18 uur uit; 2. "ON" voor continu aan;
3. "OFF" voor continu uit. **FR:** Article est à utiliser
comme décoration. Article n'est pas un jouet, gardez-le
à portée des enfants. Enregistrez cette information soigneuse-
ment. Cet ensemble d'éclairage a 3 fonctions: 1. "TIMER"
pour allumer pendant 6 heures et éteint pendant
18 heures; 2. "ON" pour allumé en continu; 3. "OFF" pour
éteint en continu. **DE:** Artikel ist nur für Dekorationszwecke
geeignet. Artikel ist kein Spielzeug. Für Kinder nicht un-
zugänglich aufbewahren. Speichern Sie diese Informationen
sorgfältig. Dieses Beleuchtungsset hat 3 Einstellungen:
1. „TIMER“ = automatisch 6 St. an und 18 St. aus; 2. „ON“ =
Dauerbetrieb; 3. „OFF“ = dauerhaft aus. **EN:** Product is suitable
for decoration purposes only. Product is not a toy, keep out
of reach of children. Save this information carefully. This light
set has 3 functions: 1. "TIMER" for switching the light on/off
automatically (6 hours on and 18 hours off); 2. "ON" for con-
tinuously switched on; 3. "OFF" for continuously switched off.



Itemnr.: 241074
MADE IN P.R.C.
Coen Bakker Deco.
Smeetsweg 4,
1738 DK WAARLAND (NL)



2 x AA (Not included)