


size:31.4x10.5cm

Product Overview

2-in-1 Smart Bowl

LCD Display Screen

Battery Box



Anti-Splashing Pad
(Anti-Pressure Transducer)

ON/OFF Button

2 Containers for Replacement



Food Grade Stainless Steel Container



Bowl Feeding ABS Container

Tech Specs

Dimension (mm)	244 (L) x 124 (W) x 46 (H)
Weight (g)	Bowl with food grade stainless steel container: 642 Bowl with food grade ABS container: 612
Material	Container Holder: ABS Container: Food grade stainless steel & food grade ABS
Working Voltage (V)	3
Voltage (mV)	75
Max Weight (g)	2000
Capacity (ml)	Food grade stainless steel container: 800 Food grade ABS container: 700
Water Resistance	Only containers are washable

Battery

Battery Type	4 pair of AA batteries
Battery Life (Use)	8 months (Use reference only)

How to install the new machine?

1. Uncover the back of the battery box on the bottom of the device and insert a pair of AA batteries, and tighten the screws.
2. Put the container into the container holder and keep the food flat on the floor or table.



3. Press the ON/OFF button on the bowl to start. It will go into the sleeping mode after 5 minutes of inactivity.

4. Press the ON/OFF button for 3 seconds to convert the measurement unit (g/oz/fl.oz).



Scientific Feeding Advice

If you want to get more scientific feeding advice from us, please download the "PETGEEK" App from App Store or Google Play and install this application on your smart phone. Next, create your own account if you don't have one. Just provide some basic information, and we will customize the feeding advice for your pet.

Operating Systems : iOS and Android
Compatible Devices : iPhone 5 and above smartphones running Android system



NOTES

1. Cleaning: Take the container out to wash and dry before putting it back. Wipe other parts with wet cloth and always keep the device dry.
2. Weighing: The weighing range is 0-2000g. When the screen shows "E00", it means that the weight is over the maximum measurable weight. You need press the ON/OFF button again to reset it. When it shows "—" it means it is not laid flat. Put it on a flat surface and press the ON/OFF button to reset it. When the digital on the display screen keeps flashing, it indicates that the bowl enters calibration mode, and you can remove the battery and reset it.
3. Filling: The container can be filled with food or water. Make sure the food is not over 2/3 and the water will not overflow into the inner part.
4. Battery Replacing: When "E" is shown on the screen, it means the battery is low. For battery replacing, it is recommended not to use old and used batteries or batteries of different brands.
5. Always keep the device in dry condition. Do not heat the device or put the device in a refrigerator. Recommended to use the device where the ambient temperature is between 0°C and 40°C.
6. Handle the device gently to avoid damage to the pressure transducer inside it.

Every Meal Counts.
So Weigh And Count Every Meal.

Download Our App



PETGEEK

2-in-1 Smart Bowl
User Manual