



## XTRFY M4 QUICK START GUIDE



### CPI


- 400
- 800
- 1200
- 1600
- 3200
- 4000
- 7200
- 16000



**POLLING RATE**




**125 Hz 500Hz 1000Hz**




**125Hz 500Hz 1000Hz**



**RGB  
EFFECTS**







+




BRIGHTNESS




+





 FOR MORE INFORMATION, DOWNLOAD THE MANUAL AT [XTRFY.COM](http://XTRFY.COM)

 FÖR MER INFORMATION, LADDA NER DEN FULLSTÄNDIGA MANUALEN PÅ [XTRFY.COM](http://XTRFY.COM)

 FOR MER INFORMASJON LAST NED BRUKSANVISNINGEN PÅ [XTRFY.COM](http://XTRFY.COM)

 FOR MERE INFORMATION, DOWNLOAD VORES FULDE MANUAL PÅ [XTRFY.COM](http://XTRFY.COM)

 LISÄTIETOJA SAAT LATAAMALLA KOKO KÄYTTÖOHJEEN [XTRFY.COM](http://XTRFY.COM)-VERKKOSIVUSTOLLA.

 FÜR WEITERE INFORMATIONEN, LADEN SIE DAS VOLLSTÄNDIGE HANDBUCH BEI [XTRFY.COM](http://XTRFY.COM)

 POUR PLUS D'INFORMATIONS, TÉLÉCHARGEZ LE MANUEL COMPLET SUR [XTRFY.COM](http://XTRFY.COM)

 SI DESEAS OBTENER MÁS INFORMACIÓN, DESCARGA EL MANUAL COMPLETO DESDE [XTRFY.COM](http://XTRFY.COM)

 PARA MAIS INFORMAÇÕES, TRANSFIRA O MANUAL COMPLETO EM [XTRFY.COM](http://XTRFY.COM)


 PER ULTERIORI INFORMAZIONI, SCARICA IL MANUALE COMPLETO SU [XTRFY.COM](http://XTRFY.COM)

 DETAYLI BILGI İÇİN LUTFEN [XTRFY.COM](http://XTRFY.COM)'DAN KULLANIM KILAVUZUNU İNDİRİN.

 WIĘCEJ INFORMACJI ZNAJDZIESZ W INSTRUKCJI OBSŁUGI, DOSTĘPNEJ NA [XTRFY.COM](http://XTRFY.COM)

 PRO VÍCE INFORMACÍ SI STÁHNĚTE KOMPLETNÍ MANUÁL NA [XTRFY.COM](http://XTRFY.COM)

 ДЛЯ ПОЛУЧЕНИЯ ДОПОЛНИТЕЛЬНОЙ ИНФОРМАЦИИ ЗАГРУЗИТЕ ПОЛНОЕ РУКОВОДСТВО НА [XTRFY.COM](http://XTRFY.COM)

 자세한 정보는 [XTRFY.COM](http://XTRFY.COM)에서 전체 매뉴얼을 다운로드하거나.

 想要得到更多信息, 请在[WWW.XTRFY.COM](http://WWW.XTRFY.COM)网站上下载说明书。

 設定や他の情報の詳細は、[xtrfy.jp](http://xtrfy.jp)から取扱説明書をダウンロードしてください。