

Operation Tips

Tips:

- 1) Use your finger to hold down the black "adjustment" button on both sides of the product, and hold on.
- 2) At the same time, adjust the middle "stand" to the ideal Angle, and then release the black "adjustment button".

