

Device Setup

Failure to follow these safety and security instructions could result in hacking threats, theft, or irreversible loss of funds.



For SAFETY

-  Do not use in wet locations, such as near a sink, bathtub, or shower stall, and don't connect or disconnect the device's USB port with wet hands.
-  Always handle the device with care. Do not throw, drop, insert the device or engage in any activities that may cause physical damage to the device.
-  The device may become warm during charging or normal use. Disconnect immediately when the device is too warm to touch or if you suspect irregular overheating.
-  Dry and slightly damp soft cloth or cotton swab can be used for cleaning the surface of the device. Do not use alcohol, other cleaning agent or any abrasive material to clean the device.

For SECURITY

-  Do not use the device if you suspect any illegal activities regarding your participation in mobile phone.
-  Do not store or share any security information online such as your PIN, password, recovery seed words or digital assets.
-  Do not store your recovery seed words on your mobile phone, hard drive or digital storage which may carry data of malware, spyware, root or theft.
-  Do not initialize, restore your device, or write down your recovery seed words in a public place where you may be exposed to public viewing and capture.
-  Keep your recovery checks in a safe place away from water and fire.

Device Setup STEP-by-STEP

Choose your SecuX wallet to continue



V20



W20



W10

Setup Link: https://secuxtech.com/howitworks/device-setup_choose-model/

Support: <https://secuxtech.com/download/>

FAQ: <https://secuxtech.com/faq/>