


Changing the carbon filters

Important


1



Important: Always unplug the appliance before changing filters. When the appliance detects that the non-washable glass HEPA filters need replacing the display on the appliance will show a solid purple bar.



2



Unplug the appliance from the main electricity supply. Slide the buttons down on either side of the shrouds.

3




To remove the carbon filters pull the tabs on both sides of the filters. Dispose of the carbon filters in the bin.

7



Press and hold the Oscillation button on the remote control.

4



Push the new carbon filters onto the base until secure.

5



Push the shrouds until they click back into position in the base.

6




Plug the appliance in to the main electricity supply and switch on.

Changing the glass HEPA filters

Important


1



Important: Always unplug the appliance before changing filters. When the appliance detects that the non-washable glass HEPA filters need replacing the display on the appliance will show a solid purple bar.




2



Unplug the appliance from the main electricity supply. Slide the buttons down on either side of the shrouds.

3



Empty the glass HEPA filters directly into the bin by pushing in both the purple tabs on the shrouds.

7



Press and hold the Night mode button on the remote control.

4



Push the new glass HEPA filters into the shrouds until secure.

5



Push the shrouds until they click back into position in the base.

6



Plug the appliance in to the main electricity supply and switch on.