

Follow the steps for usage.

- Place the correct batteries in the detector.
- Mount the detector properly by the front door, window frame, driveway, walk path, backyard, or anywhere you need.
- Then switch on the receiver and adjust the volume.
- When the detector senses motion, the receiver will make an audible sound & the LED light will flash.
- Please wait for 30 seconds after switching both units on to activate.
- Please install both units 3 feet above ground level for optimal performance.

Volg de stappen voor gebruik.

- Plaats de correcte batterijen in de detector.
- Plaats de detector stevig bij de voordeur, het raam, de oprit, de stoep, de tuin of elke andere gewenste locatie.
- Schakel de ontvanger aan en kies het gewenste geluidsvolume.
- Wanneer de detector beweging detecteert zal de ontvanger een geluid maken en het LED licht zal flitsen.
- Wacht 30 seconden na het aanzetten van de toestellen.
- Installeer beide toestellen op 1 meter hoogte voor het meest optimale gebruik.



RoHS

Made in China