Thank You For Using This Product.
Please Read This Book Carefully Before Using It!

USER MANUAL

♻ ⑱ ⓔ ⊠ ⎓

Product Brief

After turning it on, press the short
button again to start shaking.
Ten vibration modes cycle in turn

Open the key and
press the boot button,
Long press shutdown

Open the key long press boot,
again short. Press the beginning
of the vibration, 10 kinds of
vibration modes. In turn, in any
mode, Press the key to turn it off.

Magnetic suction charging hole

Specification Parameter

Product name: wireless wearable jump egg.
Product model: SM-WXCDTD-001.
Material: ABS+ silicone.
Noise: less than 60 decibels.
Battery: rechargeable lithium battery

Use Note

★ Please clean this product thoroughly before and after each
use. Ensure before cleaning The product is shut down and the
product is closed.
★ Rinse the main part with clean water and sterilizing soap,
and then use clean water.Rinse and finally wipe dry with
a towel. Do not use alcohol, petroleum-based solvent or C.
Ketone cleaner for cleaning.
★ Please cooperate with human body lubricating oil. Massage
oil, hand cream, cleaning agent are prohibited.Gasoline or
acetone is used as lubricant.
★ Please store this product in a cool, ventilated and dry place
to ensure that the product is protected from sunlight.Direct
sunlight, high temperature, heavy pressure, humidity and
pollution.
★ Connect the USB cable to a USB power adapter (excluding
the accessory) or USBPort, can use any USB power adapter for
charging.
★ It takes about 2 hours to fully charge once. According to the
residual electricity inside the appliance The specific charging
time may vary depending on the quantity.
★ The use time of this appliance after complete charging can
reach 60 - 90 minutes. For specific use Depending on the
vibration mode you choose. The higher the frequency of the
vibration mode, the more the battery is consumed.The faster.
★ There is no need to completely drain the power before
charging. In order to prolong the battery life and ensure
charging Electric effect, we suggest that you charge the
appliance before the vibration is significantly reduced.
★ If the product is automatically shut down, it may be caused
by insufficient power and start up.Self - protection mode,
please charge or replace the remote controller battery in time.

Safety Matters

As The Intimate Partner Of The Vast Number Of Users, The Mass-
Ager Can Be Used Safely And Healthily Users And Our Common
Responsibility. Now Remind Users:
★ This Product Is Only Suitable For Adults Over 18 Years Old.
Please Keep It Away From Children.
★ Please Do Not Exert Too Much Force During Use, And Pay Atte-
Ntion To Avoid Injury.
★ Do Not Mix This Product With Others. If You Feel Uncomforta-
Ble During Use, Please Stop Immediately.use This Product.
★ It Is Necessary To Regularly Check Whether The Product Is Dam
Aged. If Any Damage Is Found, It Shall Be Stopped Immediately.
★ After This Product Is Abandoned, It Shall Be Disposed Of Acc-
Ording To The Waste Electrical And Electronic Products And Rec-
Ycled To The Corresponding The Recycling Station Of Waste Ele-
Ctrical And Electronic Products. This Product Is Not Suitable For
Ordinary Garbage.

Part Name	Hazardous Substance					
	Lead And its Transformation compound (pb)	Mercury and its conversion Compound (Hg)	Tin and its chemical Compound (Cd)	Six valence chromium (Cr (VI))	Polybrominated biphenyl(PBB)	Polybrominated two benzene Ether (PBDE)
Electronic Component	800	800	80	800	800	800
Rubber Parts	800	800	80	800	800	800
Hardware Parts	800	800	80	800	800	800
Battery Components	800	800	80	800	800	800

After-sales Service

If you have any difficult problems or temporarily do not use this
massager Please contact our company as soon as you can, and
we will do our best for you.Provide quality service. However, you
are not allowed to dismantle and repair this massager without
authorization. For dismantling without authorization The com-
pany is not responsible for repaired toys.To ensure that you
enjoy after-sales service, please keep the purchase receipt or
receipt. This pressMoqi is designed and manufactured by a pro-
fessional research and development organization for adult pro-
ducts, which designs graphics and characters.Copyright belongs
to dongguan shuangmi technology co., ltd. Counterfeiting is a
must!