

6+  
YEARS

# Racing Maze

A racing challenge to test speed, nerves, & skill



SPIRAL MOUNTAIN



WHIRLWIND RAMP



PITFALL VALLEY



HIGH TRACK

## INSTRUCTIONS

Turn the unit on, using the switch on the back of the unit.

Move the ball to the starting point in the middle of the track.

Press the start button to initiate the 5 second starting countdown sequence.

When the LCD shows zero and the long beep sounds, the race has begun.

Follow the arrows on the track, as fast as you can without falling prey to the maze's pitfalls.

When you reach the finish line, the timer will stop automatically and display your time. It will also display the record time for the course.

When you have finished playing Maze Racer, then turn the unit off, by sliding the toggle switch on the rear of the unit into the off position.

To turn off the sound, press and hold the start button for 2 seconds. To turn music on, repeat the process.

If you need to reset the course record, press and hold the small button near the start button. The high score will be remembered until the reset button is pressed or the batteries are removed or exhausted.

See base of box for diagram

**(C)** WARNING! SMALL PARTS - CHOKING HAZARD. Please retain this information.

**(F)** ATTENTION! PIÈCES DE PETITE TAILLE - RISQUE D'ÉTOUFFEMENT. Conservez ces informations.

**(D)** WARNUNG! KLEINTEILE - ERSTICKUNGSGEFÄHR. Bitte diese Informationen aufbewahren.

Requires Batteries: 2 x 'AA' (3V)  
(Battery not included)  
(Please see base for battery information)



**Funline**

Funline Gifts  
London SE3 9BY  
Model No: PL7725



5376-08/2015

Made in China

6+  
YEARS

# Racing Maze

A racing challenge to test speed, nerves, & skill

CHALLENGE  
YOUR FRIENDS  
OR RACE AGAINST  
THE CLOCK  
CAN YOU MASTER  
MAZE RACER  
?



STEER YOUR WAY THROUGH THE MAZE  
IN THE FASTEST TIME POSSIBLE

OVER  
1 METRE  
OF RACE TRACK  
BUILT IN TIMER  
RECORDS FASTEST TRACK TIME  
SOUND EFFECTS  
TO BUILD TENSION