







1



2








Android™ iPhone









WH-CH500





3





Android



http://rd1.sony.net/help/mdr/whch500/h_zz/

