







# #50101


Ax10 

Bx4 


Cx2 




1




2



3



4



DE: Der Auf- und Abbau ist von Erwachsenen durchzuführen.  
 GB: Assembly/Disassembly by adults only.  
 FR: Le montage et le démontage doivent être effectués par un adulte.  
 IT: Montaggio e smontaggio devono essere effettuati solo da adulti.  
 NL: Montage/demontage moet door volwassenen worden uitgevoerd.  
 ES: El montaje y desmontaje deberá ser realizado por adultos.  
 PT: A montagem/desmontagem só deve ser efectuada por adultos.  
 CZ: Hračku mohou rozebírat a skládat jen dospělí.  
 SK: Hračku môže skladať a rozoberať len dospelá osoba.  
 SI: Postavljanje in razstavljanje se izvajajo odrasli.  
 PL: Montaż /demontaż mogą wykonywać tylko zalecane transformatory.  
 RO: Operațiile de montare/demontare se efectuează numai de către adulți.  
 HU: Az összeszerelést és szétszerelést kizárólag felnőtt végezze.  
 UA: Збиратися/розбиратися тільки дорослими.  
 KZ: Ересектер ғана жинап/бұзулары керек.  
 RU: Сборку и демонтаж разрешается выполнять только взрослым.  
 BG: да се сглобява (разглобява) само от възрастни.  
 NO: Konstruksjon og demontering skal utføres av voksne.  
 SE: Montering / demontering endast av vuxna.  
 FI: Tarkoitettu aikuisen koottavaksi/purettavaksi.  
 RS: Montaža/demontaža samo od strane odraslih.  
 TR: Montaj / Sökme işlemleri yalnızca yetişkinler tarafından yapılmalıdır.  
 HR: Montažu i demontažu mogu obavljati samo odrasle osobe.  
 DK: Må kun samles / adskilles af voksne.  
 GR: Η συναρμολόγηση και αποσυναρμολόγηση να γίνεται μόνο από ενήλικες.



Bayer Design  
 Fritz Bayer GmbH & Co. KG  
 Neuenseer Str. 57  
 D-96247 Michelau

