

reesa®

Kitchen scale

TSA0804
TSA0804W

Bedienungsanleitung

DE

Owner's manual

EN

Instrukcja obsługi

PL

Manual de utilizare

RO

Návod na použitie

SK

8. Press the "ON/TARE" button to switch off the scale if no more weighing is needed or it will auto off if no further using.

ERROR INDICATIONS

LO	Low battery	Replace batteries!
EEEE	Overload	Remove the weight

SPECIFICATION

Maximum load: 5 kg
 Minimum load: 5 g
 Graduation: 1 g
 Units: g, oz, ml, lb
 Auto off
 Tare function
 Tempered glass platform
 Power supply: CR2032 battery

Specifications are subject to change without prior notice.

EN



English
Correct Disposal of This Product
(Waste Electrical & Electronic Equipment)



(Applicable in the European Union and other European countries with separate collection systems)
 This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

Made in China for LECHPOL Zbigniew Leszek, Miętne, 1 Garwolińska Street, 08-400 Garwolin.

teesa®

www.teesa.pl