



Operation instructions



The features of product

1. The appearance design is beautiful and convenient to carry and go out.
2. Changeable universal polisher, which can meet different demands for the manicure.
3. The adjustable positive and negative rotation, 3 gears speed adjustment, LCD gears indicator.
4. Double TYPE-C interface design for chassis and fuselage, convenient and convenient.
5. Adopt a high-performance lithium battery, and USB charging indicator.
6. The function of battery status query.

Product usage

1. The polisher is better to operate:

It is more fast to switch the polisher by pulling out and plugging in it directly.

2. Start up operation

Press the power key "⏻" for 2 seconds, the machine will start to polish at 1 gear positive rotation, and the L icon light will be on.

3. Gear switch:

Press the power key "⏻" shortly to switch L-M-H gears, and the corresponding gear icon will be on.

4. Positive and negative rotation operation:

Press the positive and negative key "↔" to switch the positive rotation and negative rotation, and when the corresponding gears icon is on, the machine is at positive rotation, and when the icon is flickering, the machine is at negative rotation;

5. Shut down operation:

In the condition of operation, press the power key "⏻" for 2 seconds to shut down;

6. Shutdown condition

Power off: Short press the "⏻" button, "⏻" and L M H icon light > 70% power, "⏻" and L M icon light > 40% power, "⏻" and L icon light < 30% power;

7. Charging indication:

Plug in the USB cable, "⏻" LED flash, Charging status, If the "⏻" long bright, for the battery is full;

8. When the machine is idle without polishing for 10 minutes, it will shut down automatically.