

# *nince*

## Tabletop Fire Pit

### User Instructions & Safety Guide



This document accompanies the **Nince** Bio-Ethanol Tabletop Fire Pit and is valid for all types sold by **Nince**. It contains important information about safety and use.

Read the manual carefully and follow the instructions and warnings to ensure your own safety and the safety of others. Noncompliance with the safety rules can result in property damage, bodily injury, or even death.

Keep this document for further reference, even if you are familiar with the product. Make sure to include this document when passing on this product to third parties.

#### ■ Before Use

- Be sure to have a fire extinguisher near your Tabletop Fire Pit.
- Keep the extinguisher tool provided in the kit near the Tabletop Fire Pit.
- Remove all packaging and informational material before use.
- Keep children and pets away from the Tabletop Fire Pit.
- Children; people under the influence of alcohol, drugs, or medications; or people who are not in an appropriate physical or mental condition should not be allowed to handle the fuel, Tabletop Fire Pit, or fire accessories. The Tabletop Fire Pit should only be handled by adults.
- Always keep a safe distance of at least 1 meter from the Tabletop Fire Pit when the flame is lit.
- Never leave the fire unattended. Adult supervision is required at all times.
- Do not place any flammable materials or clothing on the Tabletop Fire Pit.
- Ensure that flammable products and materials (curtains, furniture, etc.) are at least 1m from the Tabletop Fire Pit.
- The Tabletop Fire Pit must only be put on a solid nonflammable surface.
- Do not use any petroleum products (oil, gasoline, etc.) near the Tabletop Fire Pit.
- Do not store fuel near the Tabletop Fire Pit.
- Do not place charcoal, wood, paper, or other combustible items into the burner.
- The Tabletop Fire Pit must be used strictly on a horizontal and flat surface. When placing the Tabletop Fire Pit on a table, make sure it is placed away from the edges.
- Do not use the Tabletop Fire Pit under overhanging items such as TVs, paintings, or shelves.
- Follow the manufacturer's instructions for the fuel purchased
- Never open a fuel bottle near an open flame.
- Do not smoke while lighting the Tabletop Fire Pit.
- Keep clothing and hair and hair away from Tabletop Fire Pit when lit. Clothing and hair can catch fire resulting in serious injury.
- We do not recommend placing the Tabletop Fire Pit in a bedroom or bathroom. For indoor use, only use this Tabletop Fire Pit in large, well-ventilated rooms.
- Do not use the Tabletop Fire Pit in unventilated rooms. The room should be well-ventilated with enough oxygen and fresh air being supplied.
- Do not use the Tabletop Fire Pit in tents, RVs, boats, or vehicles.
- Do not burn in a confined space.

- Exercise care when using outdoors. Do not burn during high winds or when it is raining or snowing.
- Do not blow into the fire.
- Do not obstruct or inhibit the flame.
- Do not move the Tabletop Fire Pit while it is still operating or is still hot.
- Do not burn longer than 1.5 hours at a time without letting the fire pit cool to the touch.
- Do not use the Tabletop Fire Pit if flammable gas is in the room.
- The Tabletop Fire Pit is not suitable for heating purposes.
- People with breathing problems should consult their doctor before use.

#### ■ Starting Up

- Use Isopropyl alcohol or Bio-ethanol at 70% or 91% as fuel. Fill the burner up to a maximum of 2,5cm from the edge.
- Make sure the burner is cool to the touch before pouring in the fuel.
- We recommend putting only as much fuel as you intend to use in the burner. Leftover fuel in the burner should be disposed of following regulations for hazardous materials.
- Before lighting, clean up any fuel that may have spilled and make sure any surface moisture from spillage is gone or has evaporated to prevent spillage ignition.
- Remove fuel from the area around the Tabletop Fire Pit before lighting the Tabletop Fire Pit.
- To ignite the flame, use a long-reach lighter or long matches. Be sure to keep an arm's length away when lighting.
- If the flame does not ignite, repeat the ignition process until the flame burns steadily.

#### ■ Refilling

- Never fill a burner while it is lit or still hot! Risk of explosion!
- Do not smoke while refilling or lighting the burner. Risk of explosion!
- It can be difficult to see if the flame is still lit. Be sure to double-check before you attempt to move or refill your Tabletop Fire Pit.
- Wait at least 20 minutes for the burner to cool down before refilling.
- Avoid physical contact with the fuel when preparing to light the Tabletop Fire Pit.

#### ■ Extinguishing

- Use the extinguisher tool provided in the kit for safer extinguishing.
- Never blow out the flame to put it out; this will only increase the flame.
- Don't leave fuel in the burn chamber. The flame can be snuffed out but fuel must be emptied. Wait approximately 20 minutes until the burner has reached room temperature. Only then dispose of the remaining fuel.
- Never extinguish the flame with water.

#### ■ Maintenance & Care Instructions

- Never clean the Tabletop Fire Pit while it is still operating or while the burner is still hot!
- You can use a wet cloth to clean the surface of the Tabletop Fire Pit.
- The burner can change color because of the heat.
- The stainless steel will change in appearance after a while. This is normal. Regular maintenance will preserve its color.
- The stones can be cleaned by washing with a brush and water. The burner can be cleaned with water.
- Never use chemicals, steel wool, or scrubbing sponges on the Tabletop Fire Pit.
- Do not put it in the dishwasher.

## *nince*

Imported by:  
NINN Ecommerce  
DoGood Holding BV  
Tuinstraat 28 1815TM  
Alkmaar, The Netherlands  
✉: [jordynair@gmail.com](mailto:jordynair@gmail.com)

### ⚠ WARNING

FIRE and EXPLOSION hazard.  
Severe BURNS or DEATH can occur.  
NEVER add fuel to a hot device.



© 2023 Nince

Document version 2023-07-21